





ORDER NO. ARP3506

PLASMA DISPLAY KRP-500P

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Model	Туре	Power Requirement	Remarks
KRP-500P	WYSIXK5	AC 220 V to 240 V	
KRP-500P	WYS5	AC 220 V to 240 V	
KRP-500P	LFT	AC 110 V to 240 V	
KRP-500P	WA5	AC 220 V to 240 V	



PIONEER CORPORATION 4-1, Meguro 1-chome, Meguro-ku, Tokyo 153-8654, Japan PIONEER ELECTRONICS (USA) INC. P.O. Box 1760, Long Beach, CA 90801-1760, U.S.A. PIONEER EUROPE NV Haven 1087, Keetberglaan 1, 9120 Melsele, Belgium PIONEER ELECTRONICS ASIACENTRE PTE. LTD. 253 Alexandra Road, #04-01, Singapore 159936 © PIONEER CORPORATION 2008

SAFETY INFORMATION

!

This service manual is intended for qualified service technicians; it is not meant for the casual do-it-yourselfer. Qualified technicians have the necessary test equipment and tools, and have been trained to properly and safely repair complex products such as those covered by this manual.

3

Improperly performed repairs can adversely affect the safety and reliability of the product and may void the warranty. If you are not qualified to perform the repair of this product properly and safely, you should not risk trying to do so and refer the repair to a qualified service technician.

WARNING

^B This product contains certain electrical parts contain chemicals which are known to the State of California to cause cancer, birth defects or other reproductive harm.

Health & Safety Code Section 25249.6 - Proposition 65

NOTICE

D

2

1

REMARQUE

(POUR MODÈLE CANADIEN SEULEMENT)

C Les symboles de fusible (fusible de type rapide) et/ou - (fusible de type lent) sur CCI indiquent que les pièces de remplacement doivent avoir la même désignation.

SAFETY PRECAUTIONS

NOTICE : Comply with all cautions and safety related notes located on or inside the cabinet and on the chassis. The following precautions should be observed :

- 1. When service is required, even though the PDP UNIT an isolation transformer should be inserted between the power line and the set in safety before any service is performed.
- When replacing a chassis in the set, all the protective devices must be put back in place, such as barriers, nonmetallic knobs, adjustment and compartment covershields, isolation resistorcapacitor, etc.
- 3. When service is required, observe the original lead dress. Extra precaution should be taken to assure correct lead dress in the high voltage circuitry area.
- Always use the manufacture's replacement components. Especially critical components as indicated on the circuit diagram should not be replaced by other manufacture's.
- E Furthermore where a short circuit has occurred, replace those components that indicate evidence of overheating.
 - 5. Before returning a serviced set to the customer, the service technician must thoroughly test the unit to be certain that it is completely safe to operate without danger of electrical shock,
- and be sure that no protective device built into the set by the manufacture has become defective, or inadvertently defeated during servicing. Therefore, the following checks should be performed for the continued protection of the customer and servicetechnician.

- 6. Perform the following precautions against unwanted radiation and rise in internal temperature.
- Always return the internal wiring to the original styling.
- Attach parts (Gascket, Ferrite Core, Ground, Rear Cover, Shield Case etc.) surely after disassembly.
- 7. Perform the following precautions for the PDP panel.
- When the front case is removed, make sure nothing hits the panel face, panel corner, and panel edge (so that the glass does not break).
- Make sure that the panel vent does not break. (Check that the cover is attached.)
- Handle the FPC connected to the panel carefully. Twisting or pulling the FPC when connecting it to the connector will cause it to peel off from the panel.
- 8. Pay attention to the following.
- Pay extreme caution when the front case and rear panel are removed because this may cause a high risk of disturbance to TVs and radios in the surrounding.

4

KRP-500P

2

Leakage Current Cold Check

5

With the AC plug removed from an AC power source, place a jumper across the two plug prongs. Turn the AC power switch on. Using an insulation tester (DC 500V), connect one lead to the jumpered AC plug and touch the other lead to each exposed metal part (input/output terminals, screwheads, metal overlays, control shafts, etc.), particularly any exposed metal part having a return path to the chassis. Exposed metal parts having a return path to the chassis should have a minimum resistor reading of 4 M Ω . The below 4 M Ω resistor value indicate an abnormality which

require corrective action. Exposed metal parts not having a return path to the chassis will indicate an open circuit.

Leakage Current Hot Check

Plug the AC line cord directly into an AC power source (do not use an isolation transformer for this check).

Turn the AC power switch on.

Using a "Leakage Current Tester (Simpson Model 229 equivalent)", measure for current from all exposed metal parts of the cabinet (input/output terminals, screwheads, metal overlays, control shaft, etc.), particularly any exposed metal part having a return path to the chassis, to a known earth ground (water pipe, conduit, etc.). Any current measured must not exceed 1 mA.



AC Leakage Test ANY MEASUREMENTS NOT WITHINTHE LIMITS OUTLINED ABOVE ARE INDICATIVE OF A POTENTIAL SHOCK HAZARD AND MUST BE CORRECTED BEFORE RETURNING THE SET TO THE CUSTOMER.

5

PRODUCT SAFETY NOTICE

Many electrical and mechanical parts in PIONEER set have special safety related characteristics. These are often not evident from visual inspection nor the protection afforded by them necessarily can be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in this Service Manual.

Electrical components having such features are identified by marking with a \triangle on the schematics and on the parts list in this Service Manual.

The use of a substitute replacement component which dose not B have the same safety characteristics as the PIONEER recommended replacement one, shown in the parts list in this Service Manual, may create shock, fire or other hazards.

Product Safety is continuously under review and new instructions are issued from time to time. For the latest information, always consult the current PIONEER Service Manual. A subscription to, or additional copies of, PIONEER Service Manual may be obtained at a nominal charge from PIONEER.



С

D

Е

F

3

8

[Important Check Points for Good Servicing]

In this manual, procedures that must be performed during repairs are marked with the below symbol.

2

З

Please be sure to confirm and follow these procedures.

Α

1. Product safetv Please conform to product regulations (such as safety and radiation regulations), and maintain a safe servicing environment by following the safety instructions described in this manual. ① Use specified parts for repair. Use genuine parts. Be sure to use important parts for safety. 2 Do not perform modifications without proper instructions. в Please follow the specified safety methods when modification(addition/change of parts) is required due to interferences such as radio/TV interference and foreign noise. ③ Make sure the soldering of repaired locations is properly performed. When you solder while repairing, please be sure that there are no cold solder and other debris. Soldering should be finished with the proper quantity. (Refer to the example) Make sure the screws are tightly fastened. Please be sure that all screws are fastened, and that there are no loose screws. 5 Make sure each connectors are correctly inserted. Please be sure that all connectors are inserted, and that there are no imperfect insertion. С 6 Make sure the wiring cables are set to their original state. Please replace the wiring and cables to the original state after repairs. In addition, be sure that there are no pinched wires, etc. ⑦ Make sure screws and soldering scraps do not remain inside the product. Please check that neither solder debris nor screws remain inside the product. (8) There should be no semi-broken wires, scratches, melting, etc. on the coating of the power cord. Damaged power cords may lead to fire accidents, so please be sure that there are no damages. If you find a damaged power cord, please exchange it with a suitable one. (9) There should be no spark traces or similar marks on the power plug. D When spark traces or similar marks are found on the power supply plug, please check the connection and advise on secure connections and suitable usage. Please exchange the power cord if necessary. 10 Safe environment should be secured during servicing. When you perform repairs, please pay attention to static electricity, furniture, household articles, etc. in order to prevent injuries. Please pay attention to your surroundings and repair safely. 2. Adjustments To keep the original performance of the products, optimum adjustments and confirmation of characteristics within specification. Adjustments should be performed in accordance with the procedures/instructions described in this manual. Е 3. Lubricants, Glues, and Replacement parts Use grease and adhesives that are equal to the specified substance. Make sure the proper amount is applied. 4. Cleaning For parts that require cleaning, such as optical pickups, tape deck heads, lenses and mirrors used in projection monitors, proper cleaning should be performed to restore their performances. 5. Shipping mode and Shipping screws To protect products from damages or failures during transit, the shipping mode should be set or the shipping screws should be installed before shipment. Please be sure to follow this method especially if it is specified in this manual.

KRP-500P

з

4

2

SAFETY INFORMATION	2
1. SERVICE PRECAUTIONS	6
1.1 NOTES ON SOLDERING	
1.2 NOTES SPECIFIC TO THIS PRODUCT	6
1.3 CHARGED SECTION AND HIGH VOLTAGE GENERATING POINT	7
2. SPECIFICATIONS	8
2.1 ACCESSORIES	8
2.2 SPECIFICATIONS	
2.3 PANEL FACILITIES	
3 BASIC ITEMS FOR SERVICE	15
3.1 CHECK POINTS AFTER SERVICING	15
	16
	10
4. BLOCK FRAMM	
4.1 OVERALL WIRING DIAGRAM (1/2)	20 ^в
4.2 OVERALL WIRING DIAGRAM (2/2)	
4.3 OVERALL BLOCK DIAGRAM (1/2)	24
4.4 OVERALL BLOCK DIAGRAM (2/2)	
4.5 POWER SUPPLY UNIT	
4.6 50F X DRIVE ASSY	
4.7 50F Y DRIVE, 50F SCAN A and B ASSYS	
4.8 POWER SUPPLY BLOCK of 50F X, Y DRIVE and 50F SCAN A and B ASSYS	
4.9 50F ADDRESS L and S ASSYS	
4.10 50F DIGITAL ASSY	
4.11 POWER SUPPLY BLOCK of MAIN and AUDIO ASSYS	34
5 DIAGNOSIS	35
	35 C
5.5 NON-FAILURE INFORMATION	
5.6 OUTLINE OF THE OPERATION	
5.7 OUTLINE OF RS-232C COMMAND	70 -
5.8 LIST OF RS-232C COMMANDS	71
5.9 DETAILS OF RS-232C COMMANDS	78
6. SERVICE FACTORY MODE	
6.1 DETAILS OF THE FACTORY MENU	
7. DISASSEMBLY	
7.1 FLOWCHART OF REMOVAL ORDER	
7.2 DISASSEMBLY	
8. EACH SETTING AND ADJUSTMENT	
8.1 ADJUSTMENT REQUIRED WHEN THE UNIT IS REPAIRED OR REPLACED	
8 2 BACKUP OF THE FEPBOM (DIGITAL ASSY)	123
8 3 HOW TO CLEAR HISTORY DATA	126
8.4 AD USTMENT WHEN THE SERVICE PANEL ASSY IS BEPLACED	127
	126
6.5 ADJOSTMENT WHEN THE DRIVE ASJTS ARE REFLACED	
9. EAFLODED VIEWS AND FAILS LIST	140
9.2 PACKING SECTION (KRP-500P/WYS5)	
	144 E
9.4 PACKING SECTION (KRP-500P/WA5)	
9.5 REAR SECTION	148
9.6 FRONT SECTION	150
9.7 CHASSIS SECTION (1/2)	152
9.8 CHASSIS SECTION (2/2)	154
9.9 PANEL CHASSIS SECTION	
9.10 MULTIBASE SECTION	
9.11 PDP SERVICE ASSY	

KRP-500P

F

_

1. SERVICE PRECAUTIONS 1.1 NOTES ON SOLDERING

• For environmental protection, lead-free solder is used on the printed circuit boards mounted in this unit. Be sure to use lead-free solder and a soldering iron that can meet specifications for use with lead-free solders for repairs accompanied by reworking of soldering.

З

- Compared with conventional eutectic solders, lead-free solders have higher melting points, by approximately 40 °C.
- Therefore, for lead-free soldering, the tip temperature of a soldering iron must be set to around 373 °C in general, although the temperature depends on the heat capacity of the PC board on which reworking is required and the weight of the tip of the soldering iron.

Do NOT use a soldering iron whose tip temperature cannot be controlled.

B Compared with eutectic solders, lead-free solders have higher bond strengths but slower wetting times and higher melting temperatures (hard to melt/easy to harden).

The following lead-free solders are available as service parts:

Parts numbers of lead-free solder:

GYP1006 1.0 in dia.

GYP1007 0.6 in dia.

A

С

D

F

6

1

GYP1008 0.3 in dia.

1.2 NOTES SPECIFIC TO THIS PRODUCT

In same cases, there are silicon sheets on back side of POWER SUPPLY Unit, X DRIVE Assy and Y DRIVE Assy due to
heat release of these boards to panel chassis. When replacing these boards, check backside of them and if silicon sheets
are on there, surely put these silicon sheets again to the original location of them.

KRP-500P

3

4

1.3 CHARGED SECTION AND HIGH VOLTAGE GENERATING POINT

The places where the commercial AC power is used without passing through the power supply transformer.

If the places are touched, there is a risk of electric shock. In addition, the measuring equipment can be damaged if it is connected to the GND of the charged section and the GND of the non-charged section while connecting the set directly to the commercial AC power supply. Therefore, be sure to connect the set via an insulated transformer and supply the current.

1. Power Cord

Charged Section

- 2. AC Inlet
- 3. Power Switch
- 4. Fuse (In the POWER SUPPLY Unit)
- 5. STB Transformer and Converter Transformer (In the POWER SUPPLY Unit)
- 6. Other primary side of the POWER SUPPLY Unit

High Voltage Generating Point

The places where voltage is 100 V or more except for the charged places described above. If the places are touched, there is a risk of electric shock.

А

В

С

The VSUS voltage remains for several minutes after the power to the unit is turned off. These places must not be touched until about 10 minutes after the power is turned off, or it is confirmed with a tester that there is no residual VSUS voltage.

If the procedures described in "5.6 [1] PANEL DRIVE-POWER ON/OFF FUNCTION" are performed before the power is turned off, the voltage will be discharged in about 30 seconds.

50F X DRIVE Assy	(205 V)
50F Y DRIVE Assy	(-280 V to 420 V)
50F SCAN A Assy	(-280 V to 420 V)
50F SCAN B Assy	(-280 V to 420 V)



: Part is Charged Section.

: Part is the High Voltage Generating Points other than the Charged Section.



2. SPECIFICATIONS 2.1 ACCESSORIES

2

3

4

^A ■ KRP-500P/WYSIXK5





2.2 SPECIFICATIONS

	ltem		50" display, model: KRP-500P				
	Number of pixels		1920 x 1080 pixels				
	Audio amplifier		18 W + 18 W (1 kHz, 10 %, 6 Ω)				
	Sound Effect		SRS FOCUS/SRS/SRS TruBass/SRS Definition				
	Power Requirements		220 V to 240 V AC, 50 Hz/60 Hz, 388 W (0.3 W Standby) : For WYSIXK5 and WYS5 types 110 V to 240 V AC, 50 Hz/60 Hz, 386 W (0.2 W Standby/110 V AC) : For LFT type 220 V to 240 V AC, 50 Hz/60 Hz, 409 W (0.4 W Standby) : For WA5 type				
5	Weight		Main unit: 31.4 kg (69.2 lbs) Colour Sensor: 0.1 kg (0.2 lbs) : WYSIXK5 and WYS5 types only				
	Terminals Rear	SPEAKERS	6 Ω to 16 Ω				
		SYSTEM CABLE	1				
		Colour Sensor	1				

3

4

2



KRP-500P

c Unit: mm

А

D

Е



(Colour sensor attached to the bottom right of the front panel as recommended)

KRP-500P

2

3

4

10

1

■ 2.3 PANEL FACILITIES

(Front)



7

8

А

В

С

6

(Rear)

1

2

3



- Do not connect any devices to the speaker terminals other than the speakers specified.
- Do not leave speaker cable wires bare and exposed at the terminals. Exposed wires can result in an electrical short causing malfunction or damage to the system.
- 2 SYSTEM CABLE terminal

5

- 3 Color sensor terminal LFT and WA5 types (used when connecting the optional color sensor)
- 4 RS-232C terminal (SERVICE ONLY) (used for factory setup)
- 5 AC IN terminal

6

8

Remote Control Unit (for WYSIXK5 and WYS5 types)

2

This section describes the functions of the buttons available when the TV mode has been selected by using the **SELECT** button.

1

А

в

С



- F
- 1 **OTV**: Turns on the power to the flat screen TV or places it into the standby mode.
- 2 INPUT: Selects an input source of the flat screen TV. ("INPUT 1", "INPUT 2", "INPUT 3", "INPUT 4", "INPUT 5")
- 3 Switches the screen mode among 2-screen, picture-inpicture, and single-screen.
- **4 PC:** Selects the PC terminal as an input source.
- 5 Switches between the two screens when in the 2-screen or picture-in-picture mode.

- 6 0 to 9: TV/External input mode: Selects a channel. Teletext mode: Selects a page.
- Turns the power on when the STANDBY indicator lights red.**7 EPG:** Displays the Electronic Programme Guide in DTV/SAT (Satellite) input mode.
- 8 P+/P-: TV/External input mode: Selects a channel.
- 9 **X EXIT:** Returns to the normal screen in one step.
- 10 ↑/↓/←/→: Selects a desired item on the setting screen. ENTER: Executes a command.
- 11 THOME MENU: Displays the HOME MENU screen.
- 12 Colour (RED/GREEN/YELLOW/BLUE):
 - Controls a BD player for HDMI Control functions only.
- **13** (...): Jumps to Teletext subtitle page. Turns subtitle on and off in DTV input mode depending on the broadcast.
- 14 (E): Displays hidden characters.

3

- **15 I–II:** Sets the sound multiplex mode.
- 16 TV/External input mode: Freezes a frame from a moving image. Press again to cancel the function.
 - eff: Teletext mode: Stops updating Teletext pages. Press again to release the hold mode.
- **17 TV, STB, DVD/DVR, VCR:** These indicators show the current selection and status when you control other connected equipment, using the supplied remote control unit.
- 18 (): Lights up buttons. Lights turn off if no operations are performed within five seconds. This is used for remote control use in dark locations.
- **19** (**INFO:** Displays the channel information. Displays the banner information.
- 20 HMG (Home Media Gallery): Displays the Home Media Gallery screen.
- 21 HDMI CTRL: Displays the HDMI Control menu.
- 22 Discrete the location of the small screen when in the picture-in-picture mode.
- 23 TV/DTV/SAT: Switches the mode among TV, DTV and SAT.
- 24 CH RETURN: Returns to the previous channel.
- **25** _____ +/ ____ -: Sets the volume.
- 26 🕸: Mutes the sound.
- 27 FTOOLS: Displays the TOOLS Menu.
- 28 📥 RETURN: Restores the previous menu screen.
- **29** E: Selects the Teletext mode (all TV image, all TEXT image, TV/TEXT image).
- **30** Displays an Index page for the CEEFAX/FLOF format. Displays a TOP Over View page for the TOP format.
- **31** Selects the screen size.
- **32 SELECT:** Switches the selection among TV, STB, DVD/DVR, and VCR, so that you can control other connected equipment, using the supplied remote control unit.



• When using the remote control unit, point it at the display panel.

4

1

F

KRP-500P

2

Remote Control Unit (for LFT type)

5

This section describes the functions of the buttons available when the TV mode has been selected by using the **SELECT** button.



- 1 (): Turns on the power to the flat screen TV or places it into the standby mode.
- 2 INPUT: Selects an input source. ("INPUT 1", "INPUT 2", "INPUT 3", "INPUT 4", "INPUT 5", "INPUT 6" or "PC")

5

 3 0 to 9: TV/External input mode: Selects a channel. Teletext mode: Selects a page. Turns the power on when the STANDBY indicator lights red. А

в

С

D

Е

F

- 4 CH RETURN: Returns to the previously selected channel.
- 5 P+/P-: TV/External input mode: Selects a channel.
 (■)/(■): Teletext mode: Selects a page.
- 6 HDMI CONTROL: Displays the HDMI Control menu.
- ↑↓/←/→: Selects a desired item on the setting screen.
 ENTER: Executes a command.
- 8 HOME MENU: TV/External Input mode: Displays the HOME MENU screen.
- 9 Color (RED/GREEN/YELLOW/BLUE): Teletext mode: Selects a page.
- 10 . Jumps to the Teletext subtitle page.
- 11 I: Displays hidden characters.
- 12 AV SELECTION: Selects audio and video settings. (AV source: OPTIMUM, STANDARD, DYNAMIC, MOVIE, GAME, SPORT, USER. PC source: STANDARD, USER.)
- **13** $\mathbf{I}-\mathbf{\Pi}$: Sets the sound multiplex mode.
- 14 : Press to select 2-screen, picture-in-picture or single screen mode.
- **15 TV, STB, DVD/DVR, VCR:** These indicators show the current selection and status when you control other connected equipment, using the supplied remote control unit.
- **16 CH ENTER:** Executes a channel selection by the number buttons.
- **17 +/ :** Sets the volume.
- 18 🐗: Mutes the sound.
- 19 (→ ①_{INF0}: TV/External input mode: Displays the channel information.
- 20 🗢 RETURN: Restores the previous menu screen.
- **21** (E): Selects the Teletext mode (all TV image, all TEXT image, TV/ TEXT image).
- 22 (i): Teletext mode: Displays an Index page for the CEEFAX/ FLOF format.
- **23 (F):** TV/External input mode: Selects the screen size.
- 24 (Dec TV/External input mode: Freezes a frame from a moving image. Press again to cancel the function.

E: Teletext mode: Stops updating Teletext pages. Press again to release the hold mode.

- **25** (F): Moves the position of the sub screen when in picture-inpicture mode.
- **26** Swaps the main and sub screens when in picture-inpicture or 2-screen mode.
- **27 SELECT:** Switches the selection among TV, STB, DVD/DVR, and VCR, so that you can control other connected equipment, using the supplied remote control unit.

🖉 Note

• When using the remote control unit, point it at the display panel.

13

Remote Control Unit (for WA5 type)

1

А

в

С

D

F

This section describes the functions of the buttons available when the TV mode has been selected by using the **SELECT** button.

2



- 1 O: Turns on the power to the flat screen TV or places it into the standby mode.
- 2 INPUT: Selects an input source ("INPUT 1", "INPUT 2", "INPUT 3", "INPUT 4", "INPUT 5", "INPUT 6" or "PC")
- **3 0 to 9:** TV/External input mode: Selects a channel. Turns the power on when the STANDBY indicator lights red.
- 4 CH RETURN: Returns to the previously selected channel.
- **5 P+/P-:** TV/External input mode: Selects a channel.

3

6 HDMI CONTROL: Displays the HDMI Control menu.

7 ↑/↓/←/→: Selects a desired item on the setting screen.
 ENTER: Executes a command.

- 8 HOME MENU: TV/External Input mode: Displays the HOME MENU screen.
- 9 •/II/E: Used when operating the Home Gallery function.
- **10 AV SELECTION:** Selects audio and video settings. (AV source: OPTIMUM, STANDARD, DYNAMIC, MOVIE, GAME, SPORT, USER. PC source: STANDARD, USER.)
- **11** \mathbf{I} - \mathbf{I} : Sets the sound multiplex mode.
- 12 : Press to select 2-screen, picture in picture or single screen mode.
- **13 TV, STB, DVD/DVR, VCR:** These indicators show the current selection and status when you control other connected equipment, using the supplied remote control unit.
- 14 -/--: Executes a channel selection.
- 15 \longrightarrow +/ \longrightarrow -: Sets the volume.
- 16 🕸: Mutes the sound.
- 17 (I) INFO: TV/External input mode: Displays the channel information.
- 18 🕁 RETURN: Restores the previous menu screen.
- **19** (P:TV/External input mode: Freezes a frame from a moving image. Press again to cancel the function.
- 20 EXTV/External input mode: Selects the screen size.
- 21 (: Moves the position of the sub screen when in picture in picture mode.
- 22 Swaps the main and sub screens when in picture in picture or 2-screen mode.
- **23 SELECT:** Switches the selection among TV, STB, DVD/DVR, and VCR, so that you can control other connected equipment, using the supplied remote control unit.

🖉 Note

з

• When using the remote control unit, point it at the display.

4

1

KRP-500P

3. BASIC ITEMS FOR SERVICE 3.1 CHECK POINTS AFTER SERVICING

Items to be checked after repair (PDP)

To ensure the quality of the product after repair, check the recommended items shown below:

No.	Procedures	Item to be checked
1	Check if all the symptoms pointed out by the customer have been addressed.	The symptoms in question must not be reproduced.
2	Connect the peripheral equipment.	Connect all external peripheral equipment as originally connected and check if the connections are correct.
3	Check the video and audio.	Tune in to the stations that the customer would normally receive and check if video and audio are normal.
4	Check the buttons and controls.	Use the buttons and controls on the remote control unit and main unit and check if they operate properly.
5	Check the cabinet.	Check for any scratches or dirt that have been made or attached on the cabinet after receiving the product for repair.

7

8

А

В

С

D

Е

F

See the table below for the items to be checked regarding video and audio:

Item to be checked regarding video	Item to be checked regarding audio
Block noise	Distortion
Horizontal noise	Noise
Dot noise	Volume too low
Disturbed image (video jumpiness)	Volume too high
Too dark	Volume fluctuating
Too bright	Sound interrupted
Mottled color	

Cleaning

5

Name	Part No.	Remarks					
Cleaning paper	GED-008	Used to fan cleaning. Refer to "9.7 CHASSIS SECTION (1/2)".					

7

6

3.2 QUICK REFERENCE



Quick Reference upon Service Visit ⁽²⁾ Mode transition and structure of layers in Service Factory mode



KRP-500P

6

5

7

8

A

3.3 PCB LOCATIONS

А

Note: The wiring shown in the photo is different from the actual wiring, because the product in the photo is a prototype. Upon servicing, be sure to restore the original wiring of the unit after repair work.

3

2



NOTES: • Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.

 \bullet The $m I\!L$ mark found on some component parts indicates the importance of the safety factor of the part.

Therefore, when replacing, be sure to use parts of identical designation.

2

	<u>Mark</u>	No. Description	Part No.	Mark	No.	Description	Part No.
		OF ASSEMIDLIES					
	(PDP P	anel)		(MTB))		
	NSP	50F ADDRESS L ASSY	AWW1348		MAIN	IASSY	AWW1393
Е	NSP	50F ADDRESS S ASSY	AWW1349		FAN	ASSY	AWW1394
					POW	SW ASSY	AWW1395
	NSP	50F SCAN A ASSY	AWW1350		SEN	S ASSY	AWW1396
		L IC2801 - IC2808	AN16184A		FAN	CH ASSY	AWW1397
	NSP	50F SCAN B ASSY	AWW1351		AUDI	IO ASSY	AWW1398
_		LC2901 - IC2908	AN16184A		LED	ASSY	AWW1399
					IR AS	SSY	AWW1400
		SENSOR ASSY	AWW1340		RLS	ASSY	AWW1401
		50F DIGITAL Assy	AWW1368				
				(Powe	r Supi	olv)	
		50F X DRIVE ASSY	AWV2599	`	POW	ER SUPPLY UNIT	AXY1203
		50F Y DRIVE ASSY	AWV2600				
F				(Servi	ce As	sy)	
•					PDP	SERVICE ASSY	AWU1378

KRP-500P

3

4

			KRP-500P				19
5	-	6		7	-	8	

6

5

7

А

8

в

С

D

Е







A

4.2 OVERALL WIRING DIAGRAM (2/2)





7

8

; ENSOR MODULE

K R P – 5 0 0 P / W Y S 5	
K R P – 5 0 0 P / W Y S I X K 5	Attached
K R P – 5 0 0 P / W A 5	
	Optional
K R P - 5 0 0 P / L F T	

5

5

The 🛆 mark found on some component parts should be replaced with same parts (safety regulation authorized) of identical designation.

6



OVERALL DIAGRAM KRP-500P

8

7

23

Е

F

4.3 OVERALL BLOCK DIAGRAM (1/2)





4.4 OVERALL BLOCK DIAGRAM (2/2)







А



А

POWER SUPPLY UNIT



3

4

KRP-500P

3

4

.

2

28

1

F

■ 4.6 50F X DRIVE ASSY



А

KRP-500P

4.7 50F Y DRIVE, 50F SCAN A and B ASSYS

2

3

4

50F SCAN A ASSY (HIGH-SIDE)

1

А



KRP-500P

3

4

2

30

1

4.8 POWER SUPPLY BLOCK of 50F X, Y DRIVE and 50F SCAN A and B ASSYS



50F SCAN A, B ASSYS

5

KRP-500P

6

31

8

А

В

С

D

Е

4.9 50F ADDRESS L and S ASSYS

А

в

С

D

Е

F

50F ADDRESS L ASSY DRIVER IC IC1661 DRIVER IC DRIVER IC DRIVER IC IC1651 IC1671 IC1681 CLK / LE / HBLK LBLK/R/G/B VADR1 VDDLS1 VADR2 VDDLS2 VDDLS3 VDDLS4 VADR3 VADR4 RESONANCE RESONANCE RESONANCE RESONANCE BLOCK BLOCK BLOCK BLOCK ∔ V+10V IC1601 V+3.3V V+75V LVDS RECEIVER AN/P BN/P CN/P DN/P CLKN/P AD2 AD1 CN1601 CN1602

3

4



2

KRP-500P

3

4

32

4.10 50F DIGITAL ASSY

50F DIGITAL ASSY

6

7

8

А

В

С

D

Е

F



33

4.11 POWER SUPPLY BLOCK of MAIN and AUDIO ASSYS

A									
	V+3_4V_STB								
	↓ ↓ (FET-SW Q4515)RTQ04	40P02-TLB							
	↓ I		2002 IC	27001 IC Panel E	EPROM for B	C5002 SUFFER	IC1401 232C	IC7201 SW	
	V+3_4V_STB_MAIN ↓			IAIN CPU M	AIN CPU	HC08(AND)	DRIVER	VHC126	
	↓ (FET-SW Q4513)RTQ04	40P02-TLB CN4002 50PIN	105001	105002	105005	109001	101202/2401	100700	10005
В	↓ V+3 4V ACT	For DIGITAL VIDEO ASSY	DP_RX	SPI FLASH for DP_RX	HDCP ROM for DP_RX	LVDS TR for COLOR SENSOR	TEMP SENSOR	ROOM LIGHT SENSOR	BUFFER VHC00(NAND)
•	↓ ↓ ↓ ↓ (LDO IC ↓ ↓ ↓ V+1_8V_DP ↓ ↓ (LDO IC4503)PC ↓ V+2_5V_DP	4504)NJM2846E IC5001 DP_RX Q025ENA1ZPH- IC4001-4004 BUS BUFFER	, DL3-18-TLE TLB]	3					
с	V+5_1V_STB	D2001 BLUE LED							
	↓ (LDO IC7004)N. ↓ V+3_4V_STB_REF	JM2846DL3-33- IC7001 Panel MAIN CPU	ΓLB						
D	V+6.5V ↓ ↓ ↓ (LDO IC8331)NJ ↓ ↓ ↓ V+3_3V	IM2846DL3-33-1 IC8341 PWM PROCESSOR	гів						
	↓ ↓ (LDO IC4501)NJM2871E ↓ V+5_1V_CLS	3F05-TLB CN8001 6PIN For COLOR SENSOR UNIT	.]						
E	V+12V ↓ ↓ ↓ (LDO IC1202)PC ↓ ↓	2200WNA1ZPH	TLB						
	↓ FAN_VCC1 ↓ ↓ (LDO IC1201)PQ200WN ↓ FAN_VCC2	FAN CONTRO							
F	V+17V	IC8401 D-AMP							

KRP-500P

5. DIAGNOSIS 5.1 POWER SUPPLY OPERATION

[1] LED DISPLAY INFORMATION

LED Pattern

Status	LED Display Pattern	Remarks
AC-OFF /Main PowerOFF	Blue Red	
Standby	Blue Red	
Power ON	Blue Red	
Abnormality in system connection	Blue 1000ms 1000ms 1000ms	
Power down	Blue Once Twice n times 2.5s Red 500ms 0 0	*1
Shutdown	Blue 500ms Red Once Twice n times 2.5s Once	*2
No digital adjustment data copied for backup	Blue 200ms and a second and a second a	
During download (panel main)	Blue 100ms 300ms 300ms	
During download (excepting panel main)	Blue 100ms Image: Construction of the second secon	*3

7

*1: This LED only flashes when power-down is generated in the display unit. When power-down is generated in the MR, the LED on the MR flashes.

*2: This LED only flashes when shutdown is generated in the display unit. When shutdown is generated in the MR, the LED on the MR flashes.

*3: These LEDs only flash during rewriting of software in the display unit. During rewriting of software in the MR, the LEDs on the MR flash.

5

6

35

8

8

А

D

Е

[2] POWER ON SEQUENCE

1

А

В

С

D

Е

F

2



3

4

- ①: The KEY signal is input to the IF microcomputer.
- ①': The remote control signal is input to the IF microcomputer and Panel main microcomputer.
- 2: The IF microcomputer sends the operation data of the remote control unit key to the main microcomputer.
- ③: The main microcomputer issues a startup command (PON) to the panel main microcomputer through DP Tx and DP Rx.
- ④: The panel main microcomputer issues a startup command (PON) to the MOD microcomputer.

2

- 5 : The MOD microcomputer controls a MOD relay of the POWER SUPPLY Unit (Display section), then the power is turned on.
- (5)': The main microcomputer controls a MOD relay of the POWER SUPPLY Unit (Media Receiver section), then the power is turned on.

KRP-500P

3

4
[3] DETAILS OF POWER ON SEQUENCE

6

AC-OFF

5

5



7

8

А

KRP-500P

6

37

8

Е

F

Panel Main Power OFF

А

1



KRP-500P

3

4

.

2

3

4

2

Е

38

1

F

Passive Standby

5



7

8

А

6

Only the periphery of the Panel main microcomputer and IR are operated. In this time, panel main microcomputer is the sleep mode.

5

F

Е

KRP-500P

7

6

39

Active Standby

А

1



KRP-500P

3

4

.

2

3

4

2

Е

F

1

Function Standby

5

6



KRP-500P

7

6

7

8

А

Periphery of the Panel main

microcomputer, IR, DP Rx and module microcomputer are operated. (As same state as the active standby)

5

Е

F

41

PDP Screen ON

А



Е

F

5.2 DIAGNOSIS FLOWCHART OF FAILURE ANALYSIS

[1] WHOLE UNIT



A





А [2] POWER SUPPLY UNIT



Flashing Patterns Triggered by PS_PD

Voltage waveforms at the GND terminal and Pin 3 (center pin, DGCLK) of CN201
This flashing pattern continues while AC power is supplied in PS_PD.

5

5

		3.4V		
	- -			
	۰ ۲	•		ļ
	Relay weld	d 3.4V		
	Protection against over heating or Pr overvoltage	If- 3.4V Same pattern after 5FC 0V Sams 64ms 64ms 64ms		
	Blowout of thermal fuse	5f 3.4V	8ms + 1048ms + 1048ms 1	 Same pattern after this
	Vcc6.5V overcurrent	3.4V 0V 98ms 66ms 98ms 262ms		
	Vcc6.5V over voltag	ge 3.4V	960m6 960mm5 400mm5	
	Vcc12V over voltag	ge 3.4V		
KR	Vcc17V over voltag	ge 3.4V		
P-500P	Vadr over voltag Vsus	98 04 41 0 04 41 0 04 41 0 04 41 0 04 41 0 04 41 0 04 41 0 04 41 0 04 41		
	Vcc6.5V low voltage	e 0V 282ms 282ms		
	Vcc12V low voltage	3.4V		
	Vcc17V low voltage	Je 00		
	Vadr Iow voltage	te 0.40		
	Vsus Iow voltage	le 00 00 00 00 00 00 00 00 00 00 00 00 00		

6

6

7

8

А

В

С

D

Е

F

47

*1 Repetition of the interval indicated by the arrows

7

^A [3] DRIVE ASSY

D

Е

F

-

48

1

1



3

4

2

KRP-500P

2

3

4





F

KRP-500P

		Adjustab		Measurement Point		Computation Formula for Voltage (Absolute Value)		
Assy Name	Voltage to be Checked (V)	50-inch (LFT)	50-inch (Others)	Output at the Last Stage	DAC Output (*2)	Computation Using DAC Output Voltage (V)	Computation Using Adjustment Value (*4)	
	VSNOFS	101 to 157	085 to 140	CN2404 (*1)	Lower side of R2723 (*3)	55.54 - VOFS_ADJ × 13.91	VOF value \times 0.18 + 9.6	
	VYRST	001 to 074	001 to 093	CN2401 (*1)	Upper side of R2621 (*3)	VYPRST_ADJ × 62.495 + 75.2	VRP value × 0.81 + 74.4	
	VKNOFS1_2	121 to 164	117 to 159	CN2405 (*1)	Left side of R2754 (*3)	YVKNOFS1_ADJ × 36.85 + 159.3	(V1F value+VYF value-128)	
							× 0.48 + 158.8	
ASSY	VKNOFS3	107 to 149	107 to 149	CN2403 (*1)	Right side of R2757 (*3)	YVKNOFS3_ADJ × 36.85 + 159.3	(V3F value+VYF value-128)	
							× 0.48 + 158.8	
	VKNOFS4	151 to 193	128 to 170	CN2406 (*1)	Right side of R2755 (*3)	YVKNOFS4_ADJ × 36.85 + 159.3	(V4F value+VYF value-128)	
							× 0.48 + 158.8	
X DRIVE	XKOFS1	085	085	CN1302 (*1)	K1402 (*1)	XKNOFS1_ADJ \times 27.3 + 30	VX1 value \times 0.35 + 29.7	
Assy	XKOFS2	047	047	CN1301 (*1)	K1401 (*1)	XKNOFS2_ADJ × 25.0 + 69.8	VX2 value \times 0.32 + 69.5	

5

(*1): These parts have not been mounted. (*2): It is recommended to measure the DAC output voltage with the drive off. (*3): View when the Assy is mounted on the unit and viewed from the rear.

(*4): The value calculated using an adjustment value may be different from the value measured at the last output stage, because various corrections such as temperature correction are not taken into consideration.



5

Diagrammatic view of the X DRIVE Assy

7



А	R2754,R2755,R2757
В	R2723
С	R2621
D	CN2405
Е	CN2403,CN2406
F	CN2404
G	CN2401
Н	K1401
I	K1402
J	CN1301,CN1302

А

В

С

D

Е

F

51

8

8

7



KRP-500P

No 15

No 16

0947 to 1014

1015 to 1080

[4] DIGITAL ASSY

5

5

Flowchart of Failure Analysis for The DIGITAL Assy

6



7

8

А

KRP-500P

7

6

8

Е

F

^A [5] MAIN ASSY (PANEL INTERFACE)





[6] AUDIO SYSTEM



А

Waveforms

Input signal: L/R 1 kHz, 0.5 Vrms	(VOL	30)

1 JA8551 - pins 1, 2 V: 2 V/div H: 1 mS/div	2 JA8551 - pins 3, 4 V: 2 V/div H: 1 mS/div	3 IC8401 - pins 34, 38 V: 10 V/div H: 5 μS/div	(4) IC8401 - pins 46, 50 V: 10 V/div H: 5 μS/div
			Marcini (1993) Marcininitinitininininitinitinitinitinitini
5 IC8341 - pins 40, 41 V: 2 V/div Η: 5 μS/div	6 IC8341 - pins 42, 43 V: 2 V/div Η: 5 μS/div	7 IC5001 - pins 18, 19 V: 2 V/div Η: 5 μS/div	8 IC5001 - pins 20, 21 V: 2 V/div H: 200 nS/div
		KRP-500P	

Е

F

5.3 DIAGNOSIS OF PD (POWER-DOWN)

А

[1] BLOCK DIAGRAM OF THE POWER-DOWN SIGNAL



KRP-500P

Note:

The figures (2) to (12) indicate the number of times the Red LED flashes when power-down occurs in the corresponding route.

А



KRP-500P

^A [2] PD (POWER-DOWN) DIAGNOSIS OF FAILURE ANALYSIS

1

В

С

D

Е

2

Flashing Count	History Display	Defective Assy	PD Outline	Checkpoint						
		POWER SUPPLY	Each PD in the POWER SUPPLY Unit							
2		Unit	Connector disconnection	Connector [P14][P15] (60"only)						
2		X DRIVE Assy	VSUS under voltage protection	X SUS block						
		Y DRIVE Assy	VSUS under voltage protection	Y SUS block						
		ADDRESS Assy	Connector disconnection	Connector [AD1]						
		DIGITAL Assy	Connector disconnection	Connector [D13] to [D20]						
		SCAN Assv		SCAN IC						
		X DRIVE Assy		X SUS block						
•		A Brittle Alooy	VH over or under voltage protection	X SUS block						
3	SCAN									
		Y DRIVE Assy		OFESET block						
			Connector disconnection	Connector [V1][V2]						
			Connector disconnection							
		DIGITAL ASSY								
4	SCN5V	SCAN Assy	Connector disconnection							
			IC5V over or under voltage protection	SCAN IC						
		Y DRIVE Assy								
				Y MSK block						
			VNOFS under voltage protection	NOFS block						
				VNOFS DC/DC						
			VVPRST under voltage protection	VPRST regulaotr						
			VIFNST under voltage protection	PR-U block						
			15VDD under voltage protection	15V DC/DC						
			15VDD under voltage protection	SOFT-G block						
6	Y-DCDC	Y-DCDC	Y-DCDC	Y DRIVE Assy		Y MSK block				
			VKOFS1,2 under voltage protection	KNOFS2 block						
				VYKOFS1, 2 regulatr						
				Y MSK block						
		VKOFS3 under voltage protection VYKOFS3 regulaot	VYKOES3 regulaotr							
				Y MSK block						
			VKOES4 under voltage protection	KNOES4 block						
				VYKOES4 regulactr						
7	VELIE	Y DRIVE Assy	Over or under voltage protection of the center electric potential	Y resonance block						
1	1-303	DIGITAL Assy	SO LSI does not operate	SEO LSL(Sync input_output waveform)						
		Brannie Alboy		Address resonance block						
		ADDRESS Assv	VADR under voltage protection							
		712 DT 1200 7100y	Connector disconnection	Connector [AD1][AD2]						
Q	ADBS		Connector disconnection	Connector [D12] to [D20]						
0	ADHS									
		Unit	Connector disconnection	Connector [P1][P2]						
			15VDD under voltage protection	X SUS block						
				15V DC/DC						
10	X-DCDC	X-DCDC	X-DCDC	X-DCDC	X-DCDC X DR	X DRIVE Assy	VXKOFS1 under voltage protection	VXKOFS1 regulaotr		
				X OFFSET block						
			VXKOFS2 under voltage protection	VXKOFS2 regulaotr						
				X OFFSET block						
		DIGITAL Assy	Connector disconnection	Connector [D22]						
11	X-SUS	X DRIVE Assy	Over or under voltage protection of the center electric potential	X resonance block						
			3.3V,2.5V,1.1V	DC/DC controlo IC						
12 D-DCDC DIGITAL Assy		DIGITAL Assy	Over voltage/under voltage/overcurrent protection	DC/DC block						
		POWER SUPPLY Unit	Connector disconnection	Connector [P4]						
			1							
15	UNKNOW		Connector disconnection	Connector [D23]						

3

4

58

1

F

KRP-500P

2

3

4

.

	The POWER SUPPLY Unit of 60 inches model is a structure of the two
Q1218,Q1219,Q1221-Q1223,Q1226	VSUS-SUSOUT and SUSOUT-SUSGND are short-circuited.
_Q2217-Q2224	VSUS-SUSOUT and SUSOUT-SUSGND are short-circuited.
each SCAN IC	The abnormality of the SCAN IC
01218 01210 01221-01223 01226	VSUS-SUSOUT and SUSOUT-SUSOND are short-circuited
02217 02210 02221 02223	VSUS SUSOUT and SUSOUT SUSSIND are short circuited.
Q2401,Q2402	KNOFS1 and KNOFS3 are short-circuited.
	[SB2][SC1][SC2][SD1] are 60 inches model only.
each SCAN IC	
Q2764,D2768,R2764	
Q2321-Q2326,Q2328-Q2331,Q2333,Q2334	L MSK is short-circuited.
_Q2424,Q2429	NOFS is short-circuited.
D2606,Q2709-Q2711	
Q2604,Q2605,IC2602	
Q2418	PR-U is short-circuited.
Q2662,R2669,L2301,R2335	
Q2427	SOFT-G is short-circuited.
Q2321-Q2326,Q2328-Q2331,Q2333,Q2334	L MSK is short-circuited.
Q2430	KNOFS2 is short-circuited.
Q2702,Q2705,R2714	
Q2321-Q2326,Q2328-Q2331,Q2333,Q2334	L MSK is short-circuited.
Q2703,Q2706,R2715	
Q2321-Q2326,Q2328-Q2331,Q2333,Q2334	L MSK is short-circuited.
Q2432	KNOFS4 is short-circuited.
02704 02707 B2717	
Q2106-Q2109,Q2111,Q2113,D2104-D2107	
1000004 1000000	
1C3301,1C3302	The history of SD1 remains
<u></u>	1
TCP (IC1651,IC1661,IC1671,IC1681,IC1851,IC1861,IC1871)	When the TCP is damaged, replace the panel.
	Ref No. of L Assy (6 pieces) and S Assy (2 pieces) are common
L1201,R1217	
Q1402	
Q1405,Q1406	
Q1302,Q1304	
Q1403,Q1404	
Q1301,Q1303	
Q1108,Q1112,Q1116,Q1119	
IC3801	
Q3841,Q3861,Q3881,L3841,L3861,L3881 R3820,R3848,R3868,R3888	
	EXT_PD line : Open
	EXT_PD line : Open
	It becomes "UNKNOW" except above-mentioned PD detection condition.

5

7

в

С

D

Е

F

8

5.4 DIAGNOSIS OF SD (SHUTDOWN)

А

[1] BLOCK DIAGRAM OF THE SHUTDOWN SIGNAL



KRP-500P

3

4

2

З

4

60

1

F

Note : The figures ① to ⑮ indicate the number of times the Blue LED flashes when shut-down occurs in the corresponding route.



А

[2] SD (SHUTDOWN) DIAGNOSIS

1

Α

В

С

D

Е

F

.

2

Frequency of	MojorTure	Detailed Turne	Log Indication in Factory Mode		
LED Flashing	мајог туре	Detailed Type	MAIN	SUB	
Blue 1	Abnormality in the Sequence LSI	Communication error	SQ-LSI	RTRY	
		Drive stop		SQNO	
		Busy	-	BUSY	
		Version mismatching	-	VER-HS	
		(hardware, software)			
		Version mismatching (hardware, backup memory)		VER-HM	
		Version mismatching (hardware, DIGITAL memory)	-	VER-HI	
Blue 2	Failure in module microcomputer	Digital EEPROM	MD-DEV	EEPROM	
	device communication	Backup EEPROM	1	BACKUP	
		DACIC	-	DAC	
Blue 3	Abnormality in RST2 power decrease	-	RST2	-	
Blue 4	Abnormality in panel temperature	Abnormality in high temperature	TMP-NG	TMP-H	
		Abnormality in low temperature		TMP-L	
Blue 5	Short-circuiting of the speakers	-	AUDIO	AUDIO	
	D-AMP temperature abnormality				
				OTW	
Blue 6	Failure in communication with the	-	MODULE	-	
	module microcomputer				
Blue 8	Failure in IIC communication with	Display Port Rx	PM-IIC	DP-RX	
	the panel main microcomputer	PWM Processor		PWW	
Blue 10	Abnormality in FAN	FAN1	P-FAN	FAN1	
		FAN2		FAN2	
Blue 11	High temperature of the unit	T1 (for outside)	TEMP3	T1	
		TO (fee in side)	-		
Blue 13	MAIN Assy	the MAIN Assy	MB-POW	KELAY	
Blue 15	Failure in communication with the EEPROM of the panel main microcomputer	-	-	-	

3

4

KRP-500P

2

3

4

62

Checkpoint	Possible Defective Part	Remarks
Communication line between MDU and SQ_LSI	IC3601/IC3301	SQ_IC communication not established. IC3301 may not have properly started up
Drive detectig signal of MDU (SQ_NON)	CN3201/IC3601/	A shutdown occurs if the drive waveform periodically does not output.
	IC3301/IC3607	(When SQ_NON of MDU input is High, a shutdown is generated.)
Communication line between MDU and SQ_LSI (BUSY_SQ)	IC3601/IC3301	If BUSY_SQ remains high, a shutdown is generated.
Check the DIGITAL Assy and the software version of	IC3601/IC3301	When the identification resistor of PSIZE/PLANT and software version of SEQ
SEQ and the destination of the panel.		are incoherent, a shutdown occurs.
Check the connection between [X1] and [D22].		
Check the DIGITAL Assy and the software version of	IC3601/	When the identification resistor of PSIZE/PLANT and stored content of
SEQ and the destination of the panel. Check the	SENSOR Assv(IC3902)	EEPROM on the SENSOR Assy are incoherent, a shutdown occurs.
connections between [X1] and [D22], and [SE1] and [D24].	,	· · · · · · · · · · · · · · · · · · ·
Communication line between MDU and BACKUP EEPROM		
Check the DIGITAL Assy and the software version of	IC3601/IC3602	When the identification resistor of PSIZE/PLANT and stored content of
SEQ and the destination of the panel. Check the		EEPBOM on the DIGITAL Assy are incoherent a shutdown occurs
connections between [X1] and [D22]		
Communication line between MDU and DIG EEPBOM		
Communication line between MDU and DIG EEPBOM	103601/103602	
Communication line between MDU and BACKUP EEPBOM	IC3601/SENSOB Assv(IC3902)	
Communication line between MDLL and DAC	IC3601/IC3605	
3.3 V output (TP3881) of DDC	103001/103005	If RST2 does not become high after the unit is turned on a shutdown will be
3.5 V output (1P 3881) of DDC	103001/103005	appareted in several seconds
V 6 5V of POWER SUPPLY Unit (Chock [D25][P4])		Check if V + 6 E V is started Also shock if the EU2901 on the DICITAL Assy
ELIZED to a moltod		bee been molted
		If TEMP1 that is read by the module microsomputer is 85 °C or higher a
Installation environment		a shutdown will be generated
Installation environment		Shuldown will be generated.
Installation environment	SENSOR Assy	If TEMPT that is read by the module microcomputer is -20 °C or less, a
Check the connection between [SET] and [D24].		snutdown will be generated. Also check the connection between SET and D24
Speaker terminals	JA8551	Check if any speaker cable is in contact with the chassis.
	IC8401	Check If the AMP output is short-circuited.
6.5 V power supply for AUDIO Assy	R4203	Check that V+6_5 V is activated in the AUDIO Assy.
		If it is not, check if R4203 on the MAIN Assy is open.
Periphery of the cable between MAIN and AUDIO,	CN4201,CN8301,	Check if cables are firmly connected.
and POWER SUPPLY and AUDIO Assys	CN8302	
D_AMP	IC8401	Check the temperature of D_AMP IC that is 125 °C or higher.
Communication line between main ucom and module ucom	IC7001,IC3601	Check the communication lines (TXD_MD/RXD_MD/REQ_MD).
Periphery of the cable between MAIN and DIGITAL Assys	CN4002,CN3201	Check if cables are firmly connected.
Communication line between main ucom and DisplayPort Rx	IC7001,IC5001	Check the communication lines (SCL_DP/SDA_DP).
Communication line between main ucom and PWM processor	IC7001,IC8341	Check the communication lines (SCL_AV/SDA_AV).
Periphery of the 3.3 V regulator for IC	IC8331	Check that the voltage outputs it.
Periphery of the cable between MAIN and AUDIO Assys	CN4201,CN8301	Check if cables are firmly connected.
Dirt attached to the fan motor		Check the fan. (SD10 does not detect it at the temperature that fans do not turn.)
Periphery of the cable between MAIN and FAN Assys	CN4101,CN1201	Check if cables are firmly connected.
Periphery of the cable between FAN and FAN CH Assys	CN1202,CN3304	Check if cables are firmly connected.
Periphery of the cable between FAN CH Assy and Fan motor	CN3302	Check if cables are firmly connected.
Periphery of the fan control regulator	IC1202	Check that the voltage outputs it.
Dirt attached to the fan motor		Check the fan. (SD10 does not detect it at the temperature that fans do not turn.)
Periphery of the cable between MAIN and FAN Assys	CN4101,CN1201	Check if cables are firmly connected.
Periphery of the cable between FAN and FAN CH Assys	CN1202,CN3304	Check if cables are firmly connected.
Periphery of the cable between FAN CH Assy and Fan motor	CN3301	Check if cables are firmly connected.
Periphery of the fan control regulator	IC1201	Check that the voltage outputs it.
Ambient temperature of the panel section and temp. sensor	IC1203	Shutdown occurs if the periphery of IC1203 (temp. sensor) is high temperature
Periphery of the cable between MAIN and FAN Assys	CN4101,CN1201	Check if cables are firmly connected.
Periphery of the cable between FAN and SENS Assys	CN1203,CN2401	Check if cables are firmly connected.
6.5 V power supply of the MAIN Assy	CN4502	Check if V + 6_5 V is started.
Communication line between main ucom and EEPROM	IC7001, IC7003	Check the communcation lines (SCL_E2P/SDA_E2P)

А

KRP-500P

A

С

D

[1] FUNCTION OF DECREASING THE BRIGHTNESS LEVEL

2

If the panel temperature becomes high or a video signal that requires activation of panel protection is input, the unit will protect the panel by decreasing the brightness level.

З

* While a mask is being displayed, the panel protection function will not be activated.

	Protection Function Name	Purpose	Conditions	Protection Function	Remarks
	High-temperature protection function 1	For protection of parts (DCF)	Panel temperature (TEMP1) reaches 65 °C.	Offsetting the ABL adjustment value	
	High-temperature protection function 2	For reducing heating in the unit	Panel temperature (TEMP1) reaches 80 °C.	Limiting for the maximum number of SUS pulses	
B	Panel protection function 1	For preventing burn-in	A still image is displayed for 3 minutes or more.	Limiting for the maximum number of SUS pulses	The picture will be considered to be still if only the mouse cursor is moved.
	Panel protection function 2	For protection of SCAN ICs	An image with which a particular load is applied to one SCAN IC is displayed. (See Fig. 2)	Limiting for the maximum number of SUS pulses	
	Panel protection function 3	For protection against panel cracking	An image with which the heat of part in the panel is increased is displayed. (See Fig. 3)	Limiting for the maximum number of SUS pulses	

Limiting for the maximum number of SUS pulses

By gradually decreasing the limit for the maximum number of SUS pulses, the temperature of the panel will be lowered.

- The limit for the maximum number of SUS pulses will be decreased by 8 per 5 seconds.
- The lower limit for the maximum number of SUS pulses is about 700.
- The maximum number of SUS pulses will begin to increase gradually if the conditions that led to activation of the protection function return to normal.

ABL adjustment value offset

By gradually offsetting the ABL adjustment value, the temperature of the panel will be lowered. The number of SUS pulses, which is determined based on the input APL (average picture level), will be decreased.

- The ABL adjustment value will be offset by one step per 30 seconds.
- The ABL adjustment value will be gradually restored if conditions that let to activation of the protection function return to normal.



Fig. 2: Detection example: SCAN IC protection





Fig. 3: Detection example: Protection against panel cracking

4

Input APL

Fig. 1: Relationship between input APL and number of SUS pulses



5.6 OUTLINE OF THE OPERATION

[1] PANEL DRIVE-POWER ON/OFF FUNCTION

Function:

It is an operational mode where the digital signal processing performs circuit operation but the power is not supplied to the panel driving system (Vsus, VAddress) in order to avoid a power down (PD).

Application:

- 1. When it is necessary to check whether the signal output is correctly reaching the drive system in a repairing activity etc.
- 2. In the case of a PD, to determine whether the problem is with the panel drive-power supply or with the other system power supply.

Method:

- 1. Short-circuit between the specified location of the POWER SUPPLY Unit and GND (Multi base section recommended), using a jumper with alligator clips (refer to the photos below).
- 2. Execute [DRV S00] by RS-232C command. ([DRV S01] for release)

Supplemental explanation:

- When the panel drive-power is in OFF state, there will be no PD, except PS_PD, as the PD signal has been muted.
- If the clip is removed in the OFF state of the panel drive-power, PD will take place at the instance of clip removal. Therefore, be sure to remove the clip after turning the power OFF.
- Under RS-232C command control, [DRV S01] (release) is possible during power ON. However, there is a possibility of damaging the set. Therefore, make this operation only after turning the power OFF.
- Command [DRV S00/S01] is effective even during standby.
- Setting with RS-232C commands or the remote control unit is enabled during Standby mode. However, if the unit is left unoperated for about 10 seconds in Standby mode after setting with RS-232C commands or the remote control unit is completed, the setting will become void.
- When the main power switch is set to OFF, no command is accepted.
- Setting with RS-232C commands or the remote control unit will become void if the AC power cord is unplugged, the main power switch is set to OFF, or the unit is left unoperated for about 10 seconds in Standby mode.

When the panel drive-power is ON

POWER SUPPLY Unit

5

When the panel drive-power is OFF



8

А

в

С



3



Operation specifications

1



Notes:

Е

F

66

1

- The operating temperature of the fan is higher than the ambient temperature, because the sensor temperature is read by the microcomputer.
- If the critical values for signals are displayed in the address circuit, the fan may be activated or be rotated at higher speed in response to values lower than the set temperature values shown above.
- Depending on the ventilation conditions behind the unit, the fan may be activated or be rotated at higher speed in response to values lower than the set temperature values shown above.

-500P

- When the temperature rises, the sensor voltage of TEMP3 increases.
- When the voltage of the DAC output from the Panel Main microcomputer decreases, rotation speed of the fan rises.
- Normally, the T1 temperature sensor output is used to control the fan. The T2 sensor detects the temperature inside the unit and assists T1.

	KRP
2	

3

[3] PROCESSING IN ABNORMALITY

Speaker short-circuit

5

Circuit configuration



7

8

А

в

С

D

Е

6

Specifications for port monitoring

Port Name	SD/PD Indication	Determination Condition	Monitoring conditions	Operation
A_NG_B	AUDIO	Shutdown occurs when the signal is "L." 30 mS * 10 times	DC_IN = "H" (always) (Monitoring starts 2 sec	The main CPU operations described below will be performed when either "A NG B = L" or "OTW = L" is
отw	AUDIO	Shutdown occurs when the signal is "L." 120 mS * 3 times	after the above conditions are established.)	detected (established) under the monitoring conditions.

Operation specifications of the main CPU

(1) Establish the short-circuit of the speaker by the main CPU

- After a warning indication is displayed for 5 sec, a shutdown is generated (the blue LED flashes 5 times).
- A warning indication is displayed for all input-signal types.
- Example of a warning indication: "The speaker terminals are short-circuited. After reconnection, turn the unit on again."

(2) Display conditions

When the panel is on: A warning indication is displayed immediately.

When the panel is off: A warning indication is not displayed immediately but is displayed when the panel is turned on. Note: A warning indication is displayed each time the panel is turned on if the conditions for a shutdown persist.

Conditions for resetting the circuits

The circuits will be reset upon Standby ON/OFF.

Power supply



Specifications for port monitoring

5

Port Name	SD/PD Indication	Determination Condition	Monitoring conditions	Operation		
DC_IN	PANEL MAIN power (MB-POW)	If the signal to DC IN does not become H within 5 seconds after the PON command is issued, the unit will shut itself off.	During panel screen ON	Shutdown occurs immediately Blue LED flashes 13 times		
KRP-500P						

KRP-500P

6

Fan and temperature sensor

2

• Circuit configuration

1

А

В

С



3

4

D

• Specifications for port monitoring

	Port Name	SD/PD Indication	Determination Condition	Monitoring conditions	Operation		
	FAN_NG_A FAN		Shutdown occurs when the signal is "H." 1 S * 15 times	DC_IN = H and FAN_ON_A = H (Monitoring starts 3 sec after the above conditions are established.)	Shutdown occurs immediately Blue LED flashes 10 times		
E	TEMP1	Panel temperature is high	Shutdown occurs if any values equal to or greater than minimum to require a shutdown	Digital video RST2 = H	Shutdown occurs after waiting for 30 sec. Blue LED flashes 4 times		
		Panel temperature is low	are detected. 200 mS * 5 times		Shutdown occurs after waiting for 3 sec. Blue LED flashes 4 times		
	TEMP3_1	Ambient temperature of the display	Shutdown occurs if any values equal to or greater than minimum to require a shutdown are detected. 1 S * 3 times	DC_IN = H (Monitoring starts 1 sec after the above conditions are established.)	In the Panel screen ON: Shutdown occurs after the warning indication is displayed for 30 sec. Blue LED flashes 11 times		
	TEMP3_2	Inside temperature of the display	Shutdown occurs if any values equal to or greater than minimum to require a shutdown are detected. 1 S * 3 times	DC_IN = H (Monitoring starts 1 sec after the above conditions are established.)	In the Panel screen ON: Shutdown occurs after the warning indication is displayed for 30 sec. Blue LED flashes 11 times		

1

F

KRP-500P

2

4

[4] Standalone Operation Mode

Standalone Operation mode is available with the KRP-600P and KRP-500P, by issuing the RS-232C command shown below. After disconnecting the system cable, connect an RS-232C cable to the display unit to issue a command.

А

D

Е

F

SYSS00: Standalone Operation mode SYSS01: System Operation mode

5



Notes:

5

- To update the software for the display, disconnect the system cable, connect an RS-232C cable (straight), then perform updating.
- During System Operation mode, most of the RS-232C commands are invalid.
- The setting data during Standalone Operation mode immediately before the display is turned off will be stored in memory. After finishing operation in Standalone Operation mode, be sure to issue the SYSS01 command to return the display to System Operation mode before reconnecting it to the MR. If the display is connected to the MR without returning it to System Operation mode, the MR will automatically enter Standby mode soon after it is turned on, in which case no image will be displayed even though the display is turned on.
- No audio nor video signals are output if any display port cable other than the one for this display is connected to its system cable port (terminal). The mask signal (output in response to a mask command) is the only video output available during Standalone Operation mode.
- During normal System Operation mode (SYSS01) the display monitors the connection status with the MR. If communication between the MR and the display cannot be established for any reason, such as disconnection of the system cable or MR's AC power being off, a system error warning will be indicated with the LED and on the mask screen for about 10 seconds, after which the display will automatically shut itself off. (Even after power-off, flashing of the LED for warning continues.)



Turn on with the remote control unit. (After about 7 sec.)



5.7 OUTLINE OF RS-232C COMMAND

[^] [1] PREPARED TOOLS

It is necessary to prepare the following one to use 232C command.

• PC

В

С

D

Е

F

70

1

- Application for control
- 232C cable (straight)
 - * The setting of the Com port cannot be communicated if it doesn't do correctly. (Please follow a set explanation of PC in the Com port)

KRP-500P

3

4

2

3

4

[2] USING RS-232C COMMANDS

Issue the SYSS00 command to set the unit to Standalone Operation mode.

6 5.8 LIST OF RS-232C COMMANDS

7

8

А

RS-232C command list

5

5

Command		Function		Command Receiving UCOM MOD PM		Effective only during FAY	Remarks	
ABL	***	To adjust the upper limit of power			MOD	•		
ALM	S00	To enable SD operation of the display main unit		•	PM			
	S01	To disable SD operation of the display main unit		•	PM			
AP0	S**	Addresses L1 and L2 setting	•		MOD	•	For enabling changed setting, it is necessary to	
AP1	S**	Addresses L3 and L4 setting	•		MOD	•	turn the unit off then back on again.	
AP2	S**	Addresses U1 and U2 setting	•		MOD	•		
AP3	S**	Addresses U3 and U4 setting			MOD	•		
APN	***	Average number of pulses for 1V			MOD	•		
AMP	S00	To set audio muting to OFF		•				
	S01	To set audio muting to ON		•				
в		-						
BCP		To copy EEPROM data for backup			MOD	•		
BRA	S01	To set the baud rate for the RS-232C connector on the panel to 1200 bps		•	PM		Corresponding to reception via the RS-232C	
	S02	To set the baud rate for the RS-232C connector on the panel to 2400 bps		•	PM		connector on the display	
	S03	To set the baud rate for the RS-232C connector on the panel to 4800 bps		•	PM		1	
	S04	To set the baud rate for the RS-232C connector on the panel to 9600 bps		•	PM		1	
BSM	S00	Afterimage/Burn-In Reduction mode: OFF						
	S01	Afterimage/Burn-In Reduction mode: ON						
BZS	S00	Bezel Setup: EP		٠	PM		For use by engineers	
	S01	Bezel Setup: R1 (Black)		•	PM			
	S02	Bezel Setup: R2 (White)		٠	PM			
	S03	Bezel Setup: R3 (Beige)		•	PM			
С						•		
CAL		To clear the NG (SD) history managed by the Panel Main microcomputer		•	PM	•		
CBU		To set Backup setting to "No backup"	•		MOD	•		
СНМ		To clear hour-meter data			MOD	•		
CMT		To clear stored maximum-temperature data	•		MOD	•		
CPC		To clear the power-on count			MOD	•		
CPD		To clear the power-down history			MOD	•		
CPM		To clear pulse-meter data			MOD	•		
CSD		To clear the shutdown history of the DIGITAL Assy of the display unit			MOD	•		
CSF	S00	Color sensor function: OFF						
	S01	Color sensor function: ON						
CSM	S01	Color Space mode 1: Pioneer original standard						
	S02	Color Space mode 2: In compliance with the EBU standard						
CSB	***	Color sensor blue coefficient			MOD	•		
CSG	***	Color sensor green coefficient			MOD	•		
CSR	***	Color sensor red coefficient			MOD	•		
CTP	S00	Color temperature setting: OFF						
	S01	Color temperature setting: LOW						
	S02	Color temperature setting: MID LOW						
	S03	Color temperature setting: MID						
	S04	Color temperature setting: MID HIGH						
	S05	Color temperature setting: HIGH						
D								
DIZ	S00	Dither/L dither: OFF, noise: OFF				•		
	S01	Dither/L dither: ON, noise: ON				•		
	S02	Dither/L dither: OFF, noise: ON				•		
	S03	Dither/L dither: ON, noise: OFF				•		
DRV	S00	Panel drive-power: OFF						
	S01	Panel drive-power: ON						

KRP-500P

7

6

F

8

Note: While the display is in System Operation mode (SYSS01) with the Media Receiver (MR,) among the received commands via the RS-232C connector on the display, only the SYS commands are valid. To enable other RS-232C commands, set the display to Standalone Operation mode (SYSS00).

А

	Command		Function		Command Receiving UCOM		Effective only during FAY	Remarks	
	FAJ		To set the flag for DIGITAL Assy adjustment to "Adjusted"			MOD	•		
-	FAN		Factory mode: OFF				•		
	FAY		Factory mode: ON						
	FBM	S00	OFF (disabling in-phase SUS drive)			MOD	•	For enabling changed setting, it is necessary to	
		S01	MODE 1 (enabling in-phase SUS drive)			MOD	•	turn the unit off then back on again.	
	FCP	S00	To cancel Panel FAN Control mode (Normal mode)			PM	•		
		S01	To set to Panel FAN Control MAX mode		•	PM	•		
_		S02	To set to Panel FAN Control MIN mode		•	PM	•		
В		S03	To set to Panel FAN Control STOP mode		•	PM	•		
	FSP		To set the Panel main microcomputer to factory-preset values		•	PM	•		
	L		The second		-		-		
	LED	S00	Display front indicators: All unlit				•	Corresponding to reception via the RS-232C	
		502	Display front indicators: Normal operation				•	connector on the display	
		S10	Display front indicators: ON lit				•	-	
		S11	Display front indicators: STANDBY lit				•		
	м	011							
	MIR	500	Mirror indication mode: OFF						
		S01	Mirror indication mode: Elin horizontal						
		502	Mirror indication mode: Flip vertical						
		502	Mirror indication mode: Flip horizontal and vertical						
С	MKC	500				MOD			
	WINC	S00	H DAMD (Slapt 1) M			MOD			
		802	H DAMD (Slott 4) M			MOD			
		502	RAMP (Slant 4) M			MOD			
		503				MOD			
		504	30 for aging			MOD	•		
-		505	US for aging			MOD	•		
		S06		•		MOD	•		
		S07	Afterimage wiping 2	•		MOD	•		
		S08	White (luminance change)	•		MOD	•		
		S09	Peak detection raster	•		MOD	•		
		S10	Address-lack check	•		MOD	•		
		S11	To scroll vertical green lines	•		MOD	•		
D		S12	To scroll horizontal green lines	•		MOD	•		
		S13	To scroll vertical ramp vertically (white)	•		MOD	•		
		S14	To scroll vertical ramp vertically (green)	•		MOD	•		
		S15	To scroll horizontal ramp horizontally (white)	•		MOD	•		
		S16	To scroll horizontal ramp horizontally (green)	•		MOD	•		
		S17	Crosshatch + Window			MOD	•		
	MKS	S00	MASK OFF			MOD			
		S01	H RAMP (Slant 1)	•		MOD	•		
		S02	H RAMP (Slant 4)			MOD	•		
		S03	V RAMP (Slant 1)	•		MOD	•		
		S04	Slanting ramp			MOD	•		
		S05	Window (Hi= 870, Lo= 102)			MOD	•		
E		S06	Window (Hi= 1023, Lo= 102)	•		MOD	•		
		S07	Window (Hi= 1023, Lo= 000)			MOD	•		
		S08	Window (Hi= 1023) 4%			MOD	•		
		S09	Window (Hi= 1023) 1.25%			MOD	•		
		S10	Window (1/7LINE)			MOD	•		
		S11	STRIPE (MGT/GRN)			MOD	•		
		S12	STRIPE (GRN/MGT)			MOD	•		
		S13	Checker in monochrome (1 line)			MOD	•		
		S14	Checker in monochrome (2 lines)			MOD	•		
		S15	Checker in monochrome (4 lines)			MOD	•		
		S16	Checker in monochrome (8 lines)			MOD	•		
		S17	COLOR BAR			MOD	•		
_		S18	Slanting lines			MOD	•		
-		S19	Checker in black and red (1 line)			MOD	•		
		S20	Checker in black and red (2 lines)			MOD	•		
L	L			1				1	
Command		Function	Com Receivii	mand ng UCOM	Last	Effective only	Remarks		
---------	------	--	-----------------	-----------------	---------	----------------	--		
			MOD	PM	wentory	uurniy FAT			
M	004	Observation blastly and used (4 lines)		1	MOD				
IKS	521	Checker in black and red (4 lines)	•		MOD	•			
	522	Checker in black and red (8 lines)	•		MOD	•			
	523	Afterimage wiping (RGB zigzag, v reverse)	•		MOD	•	Channe of the Deale Drichterese Detection function (DKD) impressible		
	S24	Black raster (maximum pulse count)	•		MOD	•	Change of the Peak Brightness Detection function (PKD) impossible		
	S25	1 for perfect linear	•		MOD	•			
	S26	2 for perfect linear	•		MOD	•			
	S27	3 for perfect linear	•		MOD	•			
	S28	4 for perfect linear	•		MOD	•			
	S29	RGB checker 1	•		MOD	•			
	\$30	RGB checker 2	•		MOD	•			
	\$31	Window RED (RED= 1023)	•		MOD	•			
	S32	Window GREEN (GREEN= 1023)	•		MOD	•			
	S33	Window BLUE (BLUE= 1023)	•		MOD	•			
	S34	Horizontal stripes for even-numbered lines	•		MOD	•			
	S35	Horizontal stripes for odd-numbered lines	•		MOD				
	S36	Atterimage test 1	•		MOD	•			
	S37	Atterimage test 2	•		MOD	•			
	S38	Atterimage test 3	•		MOD				
	S39	Afterimage test 4	•		MOD	•			
	S40	Slanting ramp in Red only	•		MOD	•			
	S41	Slanting ramp in Green only	•		MOD	•			
	S42	Slanting ramp in Blue only	•		MOD	•			
	S43	1 for checking lighting of the display	•		MOD	•			
	S44	2 for checking lighting of the display	•		MOD	•			
	S45	5 for perfect linear	•		MOD	•			
	S46	6 for perfect linear	•	ļ	MOD	•			
	S47	7 for perfect linear	•	ļ	MOD	•			
	S48	8 for perfect linear	•	ļ	MOD	•			
	S49	Mask for ABL adjustment	•		MOD	•			
IKR	S00	MASK OFF	•	ļ	MOD				
	S01	Raster - White	•	ļ	MOD	•			
	S02	Raster - Red	•		MOD	•			
	S03	Raster - Green	•		MOD	•			
	S04	Raster - Blue	•	ļ	MOD	•			
	S05	Raster - Black	•		MOD	•			
	S06	Raster - Cyan	•		MOD	•			
	S07	Raster - Magenta	•		MOD	•			
	S08	Raster - Yellow	•		MOD	•			
	S09	Raster - Pink	•	<u> </u>	MOD	•			
	S10	Raster - Yolk-colored	•	<u> </u>	MOD	•			
	S11	Raster - Light blue	•	<u> </u>	MOD	•			
	S12	Raster - Beige	•	<u> </u>	MOD	•			
	S13	Raster - Yellow green	•		MOD	•			
	S14	Raster - Cyan 120	•		MOD	•			
	S15	Raster - Magenta 120	•		MOD	•			
	S16	Raster - Yellow 120	•		MOD	•			
	S17	Raster - Gray 120	•		MOD	•			
	S18	Raster - Red 626	•		MOD	•			
	S19	Raster - Green 626	•		MOD	•			
	S20	Raster - Blue 626	•		MOD	•			
	S21	Raster - Red 1023+	•		MOD	•			
	S22	Raster - Green 1023+			MOD	•			
	S23	Raster - Blue 1023+			MOD	•			
	S24	Raster - Green 225	•		MOD	•			
	S25	Raster - Gray 307	•		MOD	•			

F

KRP-500P

А

	Command		Function		Command Receiving UCOM MOD PM		Effective only during FAY	Remarks
	N			1	1			
	NGP	S00	Negative/positive inverse: OFF	•				
-		S01	Negative/positive inverse: ON	•				
	Р						1	
	PAV	S00	AV selection: FACTORY					
		S01	AV selection: STANDARD/PERFORMANCE	•				
		S02	AV selection: DYNAMIC	•				
		S03	AV selection: MOVIE	•				
_		S04	AV selection: GAME	•				
в		S05	AV selection: SPORTS	•				
		S06	AV selection: PURE	•				
		S07	AV selection: USER	•				
		S08	AV selection: isf-DAY	•				
		S09	AV selection: isf-NIGHT	•				
_		S10	AV selection: OPTIMUM	•				
		S11	AV selection: isf-AUTO	•				
		S12	AV selection: Standerd	•				
		S13	AV selection: Reserved (Australian standard)	•				
	PBH	***	Panel white balance adjustment-Blue high-light	•		MOD	•	
	PBL	***	Panel white balance adjustment-Blue low-light	•		MOD	•	
	PBX	***	Panel Bx measurement value	•		MOD	•	
С	PBY	***	Panel By measurement value	•		MOD	•	
	PCS	S00	Normal operation	•				
		S01	Catalog specifications operation	•				
	PDM	S00	To enable power-down operation (To input a PD signal to the POWER SUPPLY Unit)	•				
		S01	To disable power-down operation (Not to input a PD signal to the POWER SUPPLY Unit)	•				
	PES	S00	Common to displays for consumer use: Standard	•				
		S01	Common to displays for consumer use: Power-save 1	•				
		S02	Common to displays for consumer use: Power-save 2	•				
		S10	Domestic standard for displays for consumer use: Standard	•				
		S11	Domestic standard for displays for consumer use: Power-save 1	•				
		S12	Domestic standard for displays for consumer use: Power-save 2	•				
	PFL	S**	Correction of luminance at the center of the screen	•				
D		S00	Correction of luminance at the periphery of the screen: OFF	•				
		S01	Correction of luminance at the periphery of the screen: Fixed at ON	•				
		S02	Correction of luminance at the periphery of the screen: APL-interlocked to ON	•				
	PFN		Panel module: Factory mode OFF	•			•	
	PFS		Panel module: Factory-preset settings	•		MOD	•	
	PFY		Panel module: Factory mode ON	•				Mask setting and MTB picture-quality settings remain the same.
	PGB	S00	Blue gamma setting: Straight	•				
		S01	Blue gamma setting: Fixed at 1.6	•				
		S02	Blue gamma setting: Fixed at 1.7	•				
		S03	Blue gamma setting: Fixed at 1.8	•				
		S04	Blue gamma setting: Fixed at 1.9	•				
		S05	Blue gamma setting: Fixed at 2.0	•				
F		S06	Blue gamma setting: Fixed at 2.1	•				
_		S07	Blue gamma setting: Fixed at 2.2	•				
		S08	Blue gamma setting: Fixed at 2.3	•				
		S09	Blue gamma setting: Fixed at 2.4					
		S10-31	Blue gamma setting: Customized	•				
	PGG	S00	Green gamma setting: Straight					
		S01	Green gamma setting: Fixed at 1.6					
-		S02	Green gamma setting: Fixed at 1.7					
		S03	Green gamma setting: Fixed at 1.8					
		S04	Green gamma setting: Fixed at 1.9					
		S05	Green gamma setting: Fixed at 2.0					
		S06	Green gamma setting: Fixed at 2.1					
F	L	S07	Green gamma setting: Fixed at 2.2					

0		-	Com	mand	Last	Effective only	B	
Com	mand	Function		NG UCUM PM	Memory	during FAY	Remarks	
Р					1	1		
PGG	S08	Green gamma setting: Fixed at 2.3						
	S09	Green gamma setting: Fixed at 2.4	•					
	S10-31	Green gamma setting: Customized	•					
PGH	***	Panel white balance adjustment-Green high-light			MOD	•		
PGL	***	Panel white balance adjustment-Green low-light	•		MOD	•		
PGX	***	Panel Gx measurement value	•		MOD	•		
PGY	***	Panel GY measurement value	•		MOD	•		
PGR	S00	Red gamma setting: Straight	•					
	S01	Red gamma setting: Fixed at 1.6	•					
	S02	Red gamma setting: Fixed at 1.7	•					
	S03	Red gamma setting: Fixed at 1.8	•					
	S04	Red gamma setting: Fixed at 1.9						
	S05	Red gamma setting: Fixed at 2.0	•					
	S06	Red gamma setting: Fixed at 2.1						
	S07	Red gamma setting: Fixed at 2.2						
	S08	Red gamma setting: Fixed at 2.3						
	S09	Red gamma setting: Fixed at 2.4	•					
	S10-31	Red gamma setting: Customized	•					
PKD	S00	Peak Brightness Detection: OFF	•			•		
	S01	Peak Brightness Detection: ON	•			•		
PKL	S00	No brightness limitation: 100%				-		
	S01	Brightness limitation1: 87%						
	S02	Brightness limitation2: 73%	•					
	S03	Brightness limitation3: 60%	•					
	S04	Brightness limitation4: 52%	•					
	S05	Brightness limitation5: 40%						
	S06	Brightness limitation6: 27%						
	S07	Brightness limitation7: 13%						
PMT	S00	To cancel panel muting						
	S01	Panel muting	•				Muting cannot be performed while the built-in mask signal output is being displayed.	
POF		To turn the unit OFF	•	•	PM			
PON		To turn the unit ON	•	•	PM			
PPT	S00	Panel Protection function: OFF	•	<u> </u>		•		
	S01	Panel Protection function: ON				•		
PRH	***	Panel white balance adjustment-Red high-light			MOD	•		
PRI	***	Panel white balance adjustment-Red low-light			MOD			
PRX	***	Panel Bx measurement value			MOD			
PRY	***	Panel Ry measurement value			MOD	•		
0		r and rry measurement value	-	L		-		
04 1		To acquire various adjustment values						
		To acquire the NG (SD) history managed by the Panal Main microcomputer	-					
		To acquire various data managed by the Panel Main microcomputer						
		To acquire the history of power down places		-				
		To acquire the history of power-down places						
		To acquire pulse-meter usia						
		To acquire write balance adjustment data of the panel						
		To acquire characteristics/function settings data of the panel						
000		To acquire panel information, such as software versions						
Q82		of the panel in cases of operation changes						
453		To acquire panel information other than the above						
485	<u> </u>	IO acquire panel information (Individual functions)		-				
QSB		To acquire versions of various microcomputers of the panel main unit	-					
QSP		Io acquire subversions of various microcomputers of the panel	-					
QSD		To acquire shutdown data	•					
QSI		To acquire signal-related data		1				

А

F

KRP-500P

А

	Command		Function		Command Receiving UCOM MOD RM Memory		Effective only during FAY	Remarks	
	B			MOD	РМ		J		
	B1K	***	First reset (wedge width)		[мор	•		
_	B2K	***	Second reset (wedge width)			MOD	•		
	BBI	S00-7	Correction of panel deterioration, Blue level 0 to 7			MOD	•	For apphling changed patting, it is passagery to	
	BGI	S00-7	Correction of panel deterioration, Green level 0 to 7			MOD	•	turn the unit off then back on again.	
	BLS	500	Boom light sensor operation: OFF			MICE			
		S01-5	Boom light sensor operation: 1 to 5						
								For enabling changed setting, it is necessary to	
	RRL	S00-7	Correction of panel deterioration, Red level 0 to 7	•		MOD	•	turn the unit off then back on again.	
В	S								
	SAT	***	Timing adjustment between the scan and address			MOD	•		
	SCW	S00	Normal operation						
		S01	Warning, depiction in the blue window (left)						
		S02	Warning, depiction in the red window (right)	•					
	SDM	S00	To enable shutdown operation	•					
		S01	To disable shutdown operation	•					
	SED	S01-9	Magguroment against AM radio poice: Patterns 1 to 9			MOD		For enabling changed setting, it is necessary to	
	Sin	301-0				NIOD	•	turn the unit off then back on again.	
	SKM	S00	Streaking Correction mode: OFF			MOD	•		
		S01-8	Streaking Correction mode: 1 to 8	•		MOD	•		
	SMC	S00	Smooth clear driving: OFF				•		
С		S01	Smooth clear driving: ON				•		
Ŭ	SN0	***	Serial No. setting 0 (Panel)	•		MOD	•		
	SN1	***	Serial No. setting 1 (Panel)			MOD	•		
	SN2	***	Serial No. setting 2 (Panel)			MOD	•		
	SN3	***	Serial No. setting 3 (Panel)			MOD	•		
	SN4	***	Serial No. setting 4 (Panel)			MOD	•		
	SQM	S01	VIDEO sequence setting						
		S02	PC sequence setting						
		S03	Retake sequence setting						
	SSM	S00	SSCG OFF				•		
		S01	SSCG ON				•		
	SWA	***	Estimate value for the color of the light source (absolute value)						
	SWF	S00	Reflection of estimate value for the color of the light source: OFF						
D		S01	Reflection of estimate value for the color of the light source: ON						
	SWR	***	Estimate value for the color of the light source (relative value)						
	CVC	S00	Disabling monitoring of system cable disconnection (Standalone Operation)			PM		Effective only for the RS-232C connector on the panel	
	515	S01	Enabling monitoring of system cable disconnection (System Operation)			PM		Effective only for the RS-232C connector on the panel	
	т								
	THS	S00	Interlocked operation of the theater port: OFF						
		S01	Interlocked operation of the theater port: ON						
	U								
	UAJ		To set the flag for DIGITAL Assy adjustment to "Not adjusted"			MOD	•		
	v								
	V1F	***	To adjust the reference value for Vyknofs 1 and 2 voltages			MOD	•		
	V3F	***	To adjust the reference value for Vyknofs 3 voltage			MOD	•		
Е	V4F	***	To adjust the reference value for Vyknofs 4 voltage			MOD	•		
	VFQ	S02	To set the frequency during mask display to VD-50 Hz			MOD	•		
		S03	To set the frequency during mask display to VD-60 Hz			MOD	•		
		S05	To set the frequency during mask display to VD-72 Hz			MOD	•		
		S06	To set the frequency during mask display to VD-75 Hz-1			MOD	•		
		S07	To set the frequency during mask display to VD-75 Hz-2	•		MOD	٠		
		S13	To set the frequency during mask display to PC-60 Hz	•		MOD	•		
	VOF	***	To adjust the reference value for Vysnofs voltage	•		MOD	•		
	VRP	***	To adjust the reference value for Vyprst voltage	•		MOD	٠		
	VSU	***	To adjust the reference value for Vsus voltage	•		MOD	•		
	VX1	***	To adjust the reference value for Vxpofs1 voltage	•		MOD	•		
	VX2	***	To adjust the reference value for Vxpofs2 voltage	•		MOD	•		
F	VYF	***	To adjust the reference value for Δ Vyknofs1,2/3/4 voltages	•		MOD	٠		

-

KRP-500P

Command		Function		mand ng UCOM	Last	Effective only	Remarks	
				PM	Memory	during FAY		
w								
WBI	S00	Panel WB standard output mode: OFF				•		
	S01	Panel WB standard output mode: ON				•		
х								_
X1B	***	3SF and after to First X SUS (oscillation increase amount)			MOD	•		
X3B	***	2SF to Third X SUS (oscillation increase amount)	•		MOD	•		
XSB	***	2SF to Repetition X SUS (oscillation increase amount)	•		MOD	•		
Y								
Y1K	***	1SF to Y SUSTAIL (wedge width)	•		MOD	•		
Y1Z	***	1SF to Y SUSTAIL (oscillation decrease amount)	•		MOD	•		В
Y2B	***	2SF to Second Y SUS (oscillation increase amount)	•		MOD	•		
Y2K	***	2SF to Y SUSTAIL (wedge width)	•		MOD	•		
Y2Z	***	2SF to Y SUSTAIL (oscillation decrease amount)	•		MOD	•		
YNK	***	3SF and after (2-pulse SSF) to Y SUSTAIL (wedge width)			MOD	•		
YTK	***	3SF and after to Y SUSTAIL (wedge width)			MOD	•		_
YTZ	***	3SF and after to Y SUSTAIL (oscillation decrease amount)	•		MOD	•		
YSB	***	2SF to Repetition Y SUS (oscillation increase amount)			MOD	•		

7

6

5

5

С

D

Е

F

А

8

KRP-500P

7

6

77

2 1 5.9 DETAILS OF RS-232C COMMANDS

А [1] QS1 (PANEL STATUS)

Model information and version information are returned.

Command Effective Operation Format Modes		Function	Remarks	
[QS1]	Every Time	Output of status	Return data: 3 (ECO) + 112 (DATA) + 2 (CS) = 117 Byte	

3

	Data Arrangement	Data Length	Output Example
ECO		3 byte	QS1
1	Resolution/Size	1 byte	F
2	Panel Generation	1 byte	9
3	Destination	1 byte	*
4	Grade	1 byte	*
5	Panel Product Form	1 byte	А
6	Boot version of Module microcomputer	3 byte	-01A
7	Program version of Module microcomputer	8 byte	-01A ' ' ' '
8	Boot version of sequence processor	3 byte	-01Z
9	Program version of sequence processor	8 byte	-01Z ' ' ' '
10	Panel information	8 byte	G9_50F_2
11	Derivative operation identification	1 byte	*
12	Reserved (panel section)	7 byte	*****
13	, (comma)	1 byte	,
14	MTB generation	1 byte	9
15	MTB destination	1 byte	А
16	MTB grade	1 byte	Н
17	MTB product form	1 byte	В
18	Program version of IF microcomputer	8 byte	-01A
19	Boot version of IF microcomputer	4 byte	01A
20	Program version of Main microcomputer	8 byte	-01A
21	Boot version of Main microcomputer	4 byte	01A
22	Common version of ASIC	8 byte	-01A
23	Boot version of ASIC	8 byte	01A
24	PRS version of ASIC	8 byte	-01A
25	PIC version of ASIC	8 byte	-01A
26	Common version of the Digital Tuner	8 byte	-0A
27	Boot version of the Digital Tuner	4 byte	01A
CS	2 Byte	2 byte	4A

11: Derivative Operation Identification						
*	Standard model operation					
1	Derivative model operation					

4

14: MTB Generation

G9

9

15: MTB Destination					
А	North America				
С	China				
Е	Europe				
G	General				
J	Japan				
U	Australia				

16: M	16: MTB Grade					
н	Elite/One body Europe HD /System Europe HD/One body Australia					
Т	Regular/One body Europe SD					
D	Derivative Model					
*	No Grade (Japan/General/China)					

17: MTB Product Form						
	В	One body model				
	S	System model				

1: Resolution/Size F 50-FHD (1920*1 G 60-FHD (1920*1 2: Panel Generation 9 G9

		3: Destination						
080)		*	Commonness					
080)		4: Gra	ide					
		*	Commonness					
		Z	Evaluation					
	5: Not used							
		А	"A" fixed					

2

10: Panel Information (8 Byte)				
1 to 2nd byte	G9	Generation information		
4 to 5th byte	h byte 50 50 inch			
	60	60 inch		
6th byte	F	FHD		
8th byte	3	50 inch 2nd PLANT (Reserved)		
	2	50 inch 2nd PLANT		
	1	50 inch 1st PLANT		
	ſ	Others		

4

' = space

3

KRP-500P

78

1

F

[2] QS2 (PANEL OPERATION DATA)

5

The command QS2 is for acquiring data on the panel's operational information.

6

Command Format	Effective Operation Modes	Function	Remarks
[QS2]	Every Time	Output of status	Return data: 3 (ECO) + 34 (DATA) + 2 (CS) = 39 Byte

7

	Data Arrangement	Data Length	Output Example
ECO		3 byte	QS2
1	Notify of the standby operation transition	1 byte	1
2	Adjustment flag of the main unit	1 byte	0
3	Adjustment-data backup flag	1 byte	0
4	"1st PD" data	1 byte	0
5	"2nd PD" data	1 byte	0
6	Color sensor data	1 byte	0
7	Reserved	2 byte	**
8	Temperature data (TEMP 1)	3 byte	128
9	SD data	1 byte	0
10	SD subcategory data	1 byte	0
11	Operation status induced by SD	1 byte	0
12	Reserved	3 byte	***
13	HOUR METER	8 byte	00000259
14	MASK indication	1 byte	0
15	Still picture detection	1 byte	0
16	SCAN protection detection	1 byte	0
17	Panel crack detection	1 byte	0
18	Address emergency detection	1 byte	0
19	Reserved	4 byte	****
CS	2 Byte	2 byte	4A

1: Power supply status		
Р	During power ON	
0	Shifting to Passive Standby is not possible.	
1	Shifting to Passive Standby is possible.	

2: Adjustment flag of the main unit		
0	Adjustment completed	
1	Adjustment not completed	

3: Adjustment-data backup flag		
0	Adjustment completed	
1	Adjustment not completed	
1	Adjustment not complete	

5

4, 5:	4, 5: PD data			
0	No PD data			
2	POWER			
3	SCAN			
4	SCN-5V			
6	Y-DCDC			
7	Y-SUS			
8	ADRS			
А	X-DCDC			
В	X-SUS			
С	DIG-DCDC			
F	UNKNOWN			

6: Color sensor data

-	Function OFF (including standby)
0	Normal
1	Hardware connection is not completed
2	Data mismatching

6

9: SD	9: SD data			
0	No SD			
1	SQ_LSI			
2	MDU-DEVICE			
3	RST2			
4	Panel temperature			
10-1:	SD subcategory (SQ_LSI)			
0	No SD-Sub data			
1	Communication error			
2	Drive stop			
3	BUSY			
3 4	BUSY Version mismatching (H/S)			
3 4 5	BUSY Version mismatching (H/S) Version mismatching (H/M)			

8

А

В

С

D

Е

F

79

10-2: SD subcategory (MDU-DEVICE)		
0	No SD-Sub data	
1	EEPROM	
2	BACKUP	
3	DAC	

10-3: SD subcategory (Panel temperature)			
0	No SD-Sub data		
1	Panel high temperate	ure	
2	Panel low temperatu	re	
11: (i	Dperation status nduced by SD		
0	Normal		
1	Relay-off completed		
2	During warning indication		
14: N	ASK indication		
0	MASK-OFF		
1	MASK-ON		
15 to	18: Detection of Eac	h Pro	tection funct
0	Normal operation		

KRP-500P

7

^A [3] QS3 (OTHER DATA ON THE PANEL)

1

The command QS3 is for acquiring data on operational information of the panel.

2

_	Command Format	Effective Operation Modes	Function	Remarks
	[QS3]	Every Time	Output of status	Return data: 3 (ECO) + 58 (DATA) + 2 (CS) = 63 Byte

З

4

		Data Arrangement	Data Length	Output Example	
в	ECO		3 byte	QS3	
D	1	SERIAL	15 byte		
	2	HOUR METER	8 byte	0000000	
	3	TOTAL HR METER	8 byte	0000000	
	4	PON COUNTER	8 byte	0000000	
	5	Panel temperature (*1)	5 byte	23.5	Note
	6	Reserved (TEMP0 acquisition)	5 byte	·	(*1) : Centigrade scale
	7	MAX panel temperature history (*1)	5 byte	78.3	
	8	Reserved	4 byte	***	
	cs	2 Byte	2 byte	94	

С

Е

[4] QS5 (COLOR SENSOR DATA)

The command QS5 is for acquiring the color sensor information.

D				
2	Command Format	Effective Operation Modes	Function	Remarks
	[QS5]	Every Time	Output of status	Return data: 3 (ECO) + 45 (DATA) + 2 (CS) = 50 Byte

	Data Arrangement	Data Length	Output Example
ECO		3 byte	QS5
1	Color sensor data (Note)	1 byte	2
2	RED data of color sensor	4 byte	0425
3	GREEN data of color sensor	4 byte	2112
4	BLUE data of color sensor	4 byte	5000
5	Reserved	32 byte	** to **
CS	2 Byte	2 byte	94

2

Note: The color sensor data is output as the same data as QS2.

KRP-500P

3

4

1

F

[5] QSP (SUB VERSION OF THE PANEL SECTION)

5

5

The command QSP is for acquiring sub version data on software of the panel.

6

Command Format	Effective Operation Modes	Function	Remarks
[QSP]	Every Time	Output of status	Return data: 3 (ECO) + 40 (DATA) + 2 (CS) = 45 Byte

7

	Data Arrangement	Data Length	Output Example
ECO		3 byte	QSP
1	MDUcom-PRG	8 byte	=01Y
2	MDUcom-DATA_TBL	8 byte	=01Y ````
3	SQ_LSI-PRG	4 byte	=01Y
4	SQ_LSI-PIC_TBL	8 byte	=01Y ````
5	SQ_LSI-SEQ_DATA	4 byte	=01Y
6	Reserved	8 byte	*****
CS	2 Byte	2 byte	A3

С

D

Е

F

А

в

8

KRP-500P

7

6

81

^A [6] QAJ (PANEL ADJUSTMENT DATA)

The command QAJ is for acquiring the panel's factory-preset data.

Command Format	Effective Operation Modes	Function	Remarks
[QAJ]	Every Time	Output of status	Return data: 3 (ECO) + 84 (DATA) + 2 (CS) = 89 Byte

		Data Arrangement	Data Length	Output Example
в	ECO		3 byte	QAJ
	1	Vsus adjustment value	3 byte	128
	2	Vysnofs adjustment value	3 byte	128
	3	Vyprst adjustment value	3 byte	128
	4	Vxpofs1 adjustment value	3 byte	128
	5	Vxpofs2 adjustment value	3 byte	128
	6	Vyknofs1,2 adjustment value	3 byte	128
	7	Vyknofs3 adjustment value	3 byte	128
	8	Vyknofs4 adjustment value	3 byte	128
с	9	Δ Vyknofs1,2/3/4 adjustment value	3 byte	128
	10	Reserved	6 byte	****
	11	R1K adjustment value	3 byte	128
	12	R2K adjustment value	3 byte	128
	13	Y1K adjustment value	3 byte	128
	14	Y1Z adjustment value	3 byte	128
	15	X1B adjustment value	3 byte	128
	16	Y2B adjustment value	3 byte	128
	17	X3B adjustment value	3 byte	128
П	18	YSB adjustment value	3 byte	128
D	19	XSB adjustment value	3 byte	128
	20	YTK adjustment value	3 byte	128
	21	YTZ adjustment value	3 byte	128
	22	Y2K adjustment value	3 byte	128
	23	Y2Z adjustment value	3 byte	128
	24	YNK adjustment value	3 byte	128
	25	SAT adjustment value	3 byte	128
	26	Reserved	3 byte	***
F	27	AM radio countermeasure	1 byte	1
-	28	Reserved	2 byte	**
	CS	2 Byte	2 byte	B7

27: AM radio countermeasure						
n	n: 1 to 8 (SUS frequency n)					

F

-

KRP-500P

[7] QPW (VIDEO ADJUSTMENT DATA OF THE PANEL)

5

5

The command QPW is for acquiring the factory-preset data about the video of the panel.

6

Command Effective Opera Format Modes			ration	Fund	Remarks			
[QPW]	Every Time	(Dutput of status		Return dat	a: 3 (EC	CO) + 40 (DATA) + 2 (CS) = 45 Byte
	Data Arra	ingement	Data Length	Output Example	1: Type of Drive sequence	e		
ECO			3 byte	QPW	50VS Video 50 I	Hz		
1	Type of drive	e sequence (Note 1)	4 byte	60VS	60VS Video 60 I	Hz	11, 12	, 13: RGB Gamma setting
2	ABL adjust	ment table	1 byte	1	72VS Video 72 I	Hz	n	00 to 31
3	Type of WE (Note 1)	adjustment table	1 byte	1	75V1 Video 75-	1 Hz 2 Hz	15: C	center luminance
4	ABL adjust	ment value	3 byte	128	60PS PC 60 Hz			OFF
5	R-HIGH ad	justment value	3 byte	256				
6	G-HIGH ac	ljustment value	3 byte	256	2: ABL adjustr	nent		
7	B-HIGH ad	justment value	3 byte	256			2	ON (Interlocked with APL)
8	R-LOW adj	ustment value	3 byte	512			17: I	nterlocked with APL
9	G-LOW ad	justment value	3 byte	512	3: Type of WB	table		
10	B-LOW adj	ustment value	3 byte	512	n n: 1 to 4			
11	R gamma s	setting	2 byte	31				
12	G gamma s	setting	2 byte	10			2	
13	B gamma s	setting	2 byte	10			3	WB Interlocked OFF/y ON
14	Streaking of	correction	1 byte	1			18. 1	Transition of protective
15	Center lum	inance correction	1 byte	0				operations
16	Reserved		1 byte	*			0	Upper limit state for brightness
17	Interlocked	with APL	1 byte	0			1	Brightness being reduced
18	Transition of	protective operations	1 byte	0			2	Lower limit state for brightness
19	Reserved		2 byte	**			3	Brightness being increased
CS	2 Byte		2 byte	37				

7

8

А

Note 1: The "75 Hz-2" Drive Sequence type signals and WB Adjustment Table 4 are output only when "75 Hz-2" (VFQS07) is selected for internal signals (mask signals). When external signals are selected and the Drive Sequence type is 75 Hz, "75 Hz-1" is output because "75 Hz-1" and "75 Hz-2" are not distinguished for external signals.

6

KRP-500P

7

83

8

Е

F

^A [8] QPF (FUNCTION OF THE PANEL)

2

1

Co F	ommand Format	Effective Ope Modes	ration	Function	ו	Remarks	
	[QPF]	Every Time	С	output of status		Return data: 3 (ECO) + 69 (DATA) + 2 (CS) = 74 By	te
	Data Arı	rangement	Data Length	Output Example	1:2:	3: RGB-REVISE setting value n: 0 to 7 (Level n)	
ECO			3 byte	QPF			
1	R-REVISI	E setting value	1 byte	0	5 to 8	8: ADDRESS α , β setting	
2	G-REVIS	E setting value	1 byte	0	nm	n: 0 to 9 (Address α setting PHASE n)	
3	B-REVISE	E setting value	1 byte	0		m: 0 to 9 (Address β setting PHASE m)	
4	Reserved	l	3 byte	***	10: S	Streaking correction	
5	ADDRESS	L1,L2 setting value	2 byte	01	0	OFF	
6	ADDRESS	L3,L4 setting value	2 byte	13	n	n: 1 to 8 (Mode n)	
7	ADDRESS	U1,U2 setting value	2 byte	32			
8	ADDRESS	U3,U4 setting value	2 byte	30	11: F	Full-screen black display mode	
9	Reserved		4 byte	****	0	OFF (In-phase SUS drive prohibition)	
10	Streaking	correction	1 byte	1	1	MODE1 (In-phase SUS drive permission)	
11	Full-screer	n black display mode	1 byte	1			
12	Reserved	l	4 byte	****			
13	PANEL R	х	3 byte	512			
14	PANEL R	Y	3 byte	512			
15	PANEL G	Х	3 byte	512			
16	PANEL G	Y	3 byte	512			
17	PANEL B	x	3 byte	512			
18	PANEL B	Y	3 byte	512			
19	Reserved		6 byte	****			
20	Color sen	sor R coefficient	3 byte	***			
21	Color sen	sor G coefficient	3 byte	***			
22	Color sen	sor B coefficient	3 byte	***			
23	Reserved	l	12 byte	** to **			
CS	2 Byte		2 byte	37			

3

4

.

[9] QPM (PULSE METER VALUE)

The command QPM is for acquiring the accumulated pulse count.

E	Command Format	Effective Operation Modes	Function	Remarks
	[QPM]	Every Time	Output of status	Return data: 3 (ECO) + 40 (DATA) + 2 (CS) = 45 Byte

		Data Arrangement	Data Length	Output Example	
	ECO		3 byte	QPM	
	1	Pulse meter B 1	8 byte	00000000	
	2	Pulse meter B 2	8 byte	00000000	
	3	Pulse meter B 3	8 byte	0000000	
F	4	Pulse meter B 4	8 byte	00000000	
	5	Pulse meter B 5	8 byte	0000000	Note: The minimum for a returned value of the pulse meter for each
	CS	2 Byte	2 byte	E7	block (B1-B2) is one million.
8	4	1 🗖		KRP-5	00P 3 ■ 4

[10] QPD (POWER DOWN LOGS)

5

5

The command QPD is for acquiring data from the 8 latest power-down (PD) logs.

6

Command Format	Effective Operation Modes	Function	Remarks
[QPD]	Every Time	Output of status	Return data: 3 (ECO) + 80 (DATA) + 2 (CS) = 85 Byte

7

	Data Arrangement	Data Length	Output Example	• PI	D data
ECO		3 byte	QPD	0	No F
1	Latest "1st PD" data	1 byte	А	2	P-PC
2	Latest "2nd PD" data	1 byte	2	3	SCA
3	Data from the hour meter for the latest PD	8 byte	00010020	4	SCN
4	Second latest "1st PD" data	1 byte	E	6	Y-DC
5	Second latest "2nd PD" data	1 byte	9	7	Y-SL
6	Data from the hour meter for the second latest PD	8 byte	00008523	8	Addr
7	Third latest "1st PD" data	1 byte	4	A	X-D0
8	Third latest "2nd PD" data	1 byte	3	В	X-SL
9	Data from the hour meter for the third latest PD	8 byte	00004335	C C	DIGI
10	Fourth latest "1st PD" data	1 byte	2	F	UNK
11	Fourth latest "2nd PD" data	1 byte	0		
12	Data from the hour meter for the fourth latest PD	8 byte	00000945		
13	Fifth latest "1st PD" data	1 byte	4		
14	Fifth latest "2nd PD" data	1 byte	0		
15	Data from the hour meter for the fifth latest PD	8 byte	00000715		
16	Sixth latest "1st PD" data	1 byte	А		
17	Sixth latest "2nd PD" data	1 byte	2		
18	Data from the hour meter for the sixth latest PD	8 byte	00000552		
19	Seventh latest "1st PD" data	1 byte	A		
20	Seventh latest "2nd PD" data	1 byte	0		
21	Data from the hour meter for the seventh latest PD	8 byte	00000213		
22	Eighth latest "1st PD" data	1 byte	D		
23	Eighth latest "2nd PD" data	1 byte	0		
24	Data from the hour meter for the eighth latest PD	8 byte	000001A7		
CS	2 Byte	2 byte	27		

6

_	
	No PD
	P-POWER
	SCAN
	SCN-5V
	Y-DCDC
	Y-SUS
	Address
	X-DCDC
	X-SUS
	DIGI-DCDC
	UNKNOWN

8

С

D

Е

F

А

В

7

85

^A [11] QSD (SHUTDOWN LOGS of the Panel Section)

The command QSD is for acquiring the data from the 8 latest shutdown (SD) logs of the panel section.

_	Co	mmand ormat	Effective Operation Modes		Function	1			Remarks
	[[[QSD]	Every Time	Output of statu	IS		Return data	a: 3 (EC	O) + 80 (DATA) + 2 (CS) = 85 Byte
			Data Arrangement		Data Length	Output Exa	mple	• SD	data
	FCO				3 hyte	050	_		
В	1	Latest SD	data		1 byte	1			
	2	Latest SD	subcategory data		1 byte	0			
	3	Data from	the hour meter for the lates	t SD	8 byte	0075201	3		Ranal temperature
	4	Second la	test SD data		1 byte	5	<u> </u>	4	
_	5	Second la	test SD subcategory data		1 byte	0		• SD	subcategory (SQ_LSI)
	6	Data from	the hour meter for the seco	nd latest SD	8 byte	00495204	4	0	No SD-Sub data
	7	Third lates	t SD data		1 byte	2		1	Communication error
	8	Third lates	t SD subcategory data		1 byte	3		2	Drive stop
	9	Data from	the hour meter for the third	latest SD	8 byte	0010035	5	3	BUSY
С	10	Fourth late	est SD data		1 byte	2		4	Version mismatching (H/S)
	11	Fourth late	est SD subcategory data		1 byte	5		5	Version mismatching (H/M)
	12	Data from	the hour meter for the fourth	h latest SD	8 byte	00075620	0	6	Version mismatching (H/I)
	13	Fifth latest	SD data		1 byte	1			
_	14	Fifth latest	SD subcategory data		1 byte	0		• 50	
	15	Data from	the hour meter for the fifth I	atest SD	8 byte	00000852	2		No SD-Sub data
	16	Sixth lates	t SD data		1 byte	2			EEPROM
	17	Sixth lates	t SD subcategory data		1 byte	2		2	BACKUP
	18	Data from	the hour meter for the sixth	latest SD	8 byte	0000045	1	3	DAC
D	19	Seventh la	test SD data		1 byte	0			au haata wa wu
0	20	Seventh la	test SD subcategory data		1 byte	0		• 5D (Pa	nel temperature)
	21	Data from	the hour meter for the seve	nth latest SD	8 byte	0000000	0	0	No SD-Sub data
	22	Eighth late	est SD data		1 byte	0		1	TEMP1 (high temperature)
	23	Eighth late	est SD subcategory data		1 byte	0		2	TEMP1 (low temperature)
	24	Data from	the hour meter for the eight	h latest SD	8 byte	0000000	0	L	
	CS	2 Byte			2 Byte	7D			

Е

F

KRP-500P

[12] QSI (INPUT SIGNAL DATA)

5

The command QSI is for acquiring all data on input video signals.

6

Command Format	Effective Operation Modes	Function	Remarks
[QSI]	Every Time	Output of status	Return data: 3 (ECO) + 66 (DATA) + 2 (CS) = 71 Byte

7

8

А

В

С

D

Е

F

	Data Arrangement	Data Length	Output Example	18 to 20: Each protection function
ECO		3 Byte	QSI	0 Setting: OFF
1	Type of drive sequence (Note)	4 Byte	60VS	1 Setting: ON (during wait)
2	Type of ABL adjustment table (Note)	1 Byte	1	2 Setting: ON (during operation)
3	Type of WB adjustment table (Note)	1 Byte	1	
4	Reserved	4 Byte	****	21: Transition of protection
5	Total value of PRH	4 Byte	0256	
6	Total value of PGH	4 Byte	0256	0 Upper limit status for brightness
7	Total value of PBH	4 Byte	0256	1 Brightness being reduced
8	Reserved	4 Byte	****	2 Lower limit status for brightness
9	Total value of PRL	4 Byte	0512	3 Brightness being increased
10	Total value of PGL	4 Byte	0512	
11	Total value of PBL	4 Byte	0512	22: Address emergency status
12	Total value of ABL	3 Byte	128	0 Normal status
13	V frequency distinction	4 Byte	6002	1 Emergency status
14	Reserved	4 Byte	****	
15	APL acquiring data	4 Byte	1023	23: Reset operation status
16	Number of SUS pulses	4 Byte	0457	A All reset operation
17	Detection status of still picture	1 Byte	1	2 Interlace 1/2 reset operation
18	Detection status of cracking in the panel	1 Byte	1	4 Interlace 1/4 reset operation
19	Detection status of SCAN protection	1 Byte	1	L Reset less operation (specifications
20	Detection status of external protection	1 Byte	1	operation)
21	Transition of protection operations	1 Byte	0	
22	Address emergency status	1 Byte	1	24: In-phase SUS mode status
23	Detection status of reset operation	1 Byte	1	0 Normal status
24	In-phase SUS mode status	1 Byte	1	1 In-phase SUS mode status
25	Reserved	1 Byte	1	2 Assist status at the cancellation
CS	2 Byte	2 Byte	27	

Note: The types of drive sequence and ABL/WB table are output as the same data as QPW.

5

KRP-500P

7

6

87

^A [13] DRV (PANEL DRIVE-POWER ON/OFF)

1

В

Panel drive-power ON/OFF (drive ON/OFF) is controllable.

	Operation		
Command Format	Effective Operation Modes	Function	Remarks
[DRV+S00]	Every time	DRIVE OFF	If a command is issued in Standby mode, and the unit is left unoperated for more than 10 seconds, the command will become void.
[DRV+S01]	Every time	DRIVE ON (default)	

3

4

Note: The function of the DRIVE OFF key on the remote control unit for servicing is the same as that of the DRVS00 command. (A function equivalent to that of the DRVS01 command is not provided for the remote control unit for servicing.)

[14] FAY/FAN (ADJUSTMENT COMMANDS PERMISSION/PROHIBITION)

The commands FAY/FAN are for prohibiting/permitting panel/MTB-adjustment commands.

2

		O	peration		
с	Format	Effective Operation Modes	Control	Remarks	
	[FAY]	Normal operation mode while the power is on	Adjustment command is valid.	For details, refer to the section "6.1 [3] FUNCTIONS WHEN ENTERING THE SERVICE FACTORY MODE" of the Service Manual for Media Receiver (KRP-M01).	
	[FAN]	During FAY	Adjustment command is invalid.		

[15] FAJ/UAJ/CBU/BCP (BACKUP FUNCTION FOR ADJUSTMENT VALUE)

^D When the DIGITAL Assy is to be replaced, adjustment values can be copied from the backup EEPROM to the EEPROM of the Assy for service.

	Command		Operation		
	Format	Effective Operation Modes	Control	Remarks	
	[FAJ]		To make the status of the EEPROM on the DIGITAL Assy "adjustment completed" and copy the data to the EEPROM for backup	This takes at least 350 msec.	
	[UAJ]		To make the status of the EEPROM on the DIGITAL Assy "adjustment not completed"	Only the status is changed, and the real data are not erased.	
E	[CBU]	Duning I AT	To make the status of the EEPROM on for backup "adjustment not completed"	Only the status is changed, and the real data are not erased. However, if the status of the EEPROM on the DIGITAL Assy is "adjustment completed," the data in the EEPROM of the DIGITAL Assy will be copied to the EEPROM for backup upon POF.	
	[BCP]		To copy the backup data from the EEPROM for backup to the EEPROM on the DIGITAL Assy		

3

4

2

1

F

[16] QSB

Data on models and versions of the Module microcomputer and Panel Main microcomputer can be acquired.

Command Format	Effective status	Function	Remarks
[QSB]	Every time	To acquire versions of various programs managed by the Panel Main and Module microcomputers	Return data: 3 (ECO) + 87 (DATA) + 2 (CS) = 92 Byte

А

		Data Arrangement	Data Length	Output Example	Remarks	В
ECO	Echo back		3	"QSB"		
1		Display data 1 (resolution, size)	1	F	See QS1.	
2		Display data 2 (generation)	1	9	See QS1.	
3		Display data 3 (destination)	1	*	See QS1.	
4		Display data 4 (grade)	1	*	See QS1.	-
5		Display data 5 (product style)	1	А	See QS1.	
6		Boot version of the Module microcomputer	3	01A	See QS1.	
7	Data managed by the Module	Program version of the Module microcomputer (common program of the MD microcomputer)	8	001A ' ' ' '	See QS1.	С
8	microcomputer	Boot version of the later ASIC (SQ_LSI Boot)	3	01H	See QS1.	
9		Program version of the later ASIC (common program of the SQ_LSI)	8	001Y ' ' ' '	See QS1.	
10	1	PANEL INFO	8	G9_50F_2	See QS1.	
11		Reserved	8		(All digits are padded with asterisks.)	
12		Delimiter	1	"",		
13		Dummy	4	"****"		
			3	- 01	Version of the program	_
			1	А	A (fixed)	D
14		Version data of the Papel Main microcomputer	1	S	S (fixed)	
14			3	Space	Reserved for the version of the program	
	Data managed		1	Space	Reserved for the version of the boot program	
	by the Panel Main		3	07A	Version of the boot program	
15	microcomputer	Model data (Bezel color data, etc.)	1	1	1: R1 (ROM Table 1, 2: R2 (ROM Table 2), 3: R3 (ROM Table 3), E: EP (For use by engineers)	
16		Firmware version data of the Displayport_Rx	16	1.10	Version of the program	
17		Firmware version data of the Displayport_Rx	4	0C15	Version of hardware	-
18		Reserved	6		"Space"	E
CS	Check sum		2	(CS)		

KRP-500P

F

^A [17] QPB (Panel Main Operation Information)

Data on operation of the display main unit can be acquired.

_	Command Format	Effective status	Function	Remarks
•	[QPB]	Every time	To acquire data on current statuses managed by the Panel Main microcomputer	Return data: 3 (ECO) + 53 (DATA) + 2 (CS) = 58 Byte

В	Data Arrangement		Data Length	Output Example	Remarks
	ECO	Echo back	3	"QPB"	
	1	Data on panel temperature	5	****	Temperature of the panel (in Centigrade) (Tmd)
	2	Delimiter	1	" " ,	Comma
	3	Unit temperature data 1	5	****	Temperature inside the unit (in Centigrade) (T1)
-	4	Delimiter	1	" " ,	Comma
	5	Unit temperature data 2 (reserved)	5	****	Temperature inside the unit (in Centigrade) (T2) (Reserved, All digits are padded with asterisks.)
	6	Delimiter	1	11 11 3	Comma
С	7	Unit temperature data 3 (reserved)	5	****	Temperature inside the unit (in Centigrade) (T3) (Reserved, All digits are padded with asterisks.)
	8	Delimiter	1	","	Comma
	9	Fan rotation speed A	1	А	Fan setting A (S: stop, L: Low, H: High, and A: Auto)
	10	Fan control A/D value (A)	3	***	Fan control D/A value, A, decimal code
	11	Fan rotation speed B	1	А	Fan setting B (S: stop, L: Low, H: High, and A: Auto)
	12	Fan control A/D value (B)	3	***	Fan control D/A value, B, decimal code
	13	Room Light Sensor level	1	5	0-7, padded with an asterisk during the sensor is off
	14	Room Light Sensor A/D value	4	****	Brightness sensor A/D value, decimal code
_	15	Dummy 1	2	**	All digits are padded with asterisks.
D	16	System Operation mode of the panel	1	S	S: System Operation mode, T: Standalone Operation mode
	17	Dummy 2	2	**	All digits are padded with asterisks.
	18	Audio muting	1	0	0: Canceling muting, 1: Muting
	19	Reserved	10	**	All digits are padded with asterisks.
	CS	Check sum	2	(CS)	

Е

F

[18] QAL (Shutdown information for the display main unit)

6

Command Format	Effective status	Function	Remarks
[QAL]	Every time	To acquire up to the 8 latest shutdown logs managed by the Panel Main microcomputer	Return data: 3 (ECO) + 96 (DATA) + 2 (CS) = 101 Byte

7

8

А

В

Up to the 8 latest shutdown logs of the display main unit can be acquired.

	Data Arrangement	Data Length	Output Example	Remarks	
ECO	Echo back	3	"QAL"		
1	Data on the latest shutdown	12			
2	Data on the 2nd latest shutdown	12			
3	Data on the 3rd latest shutdown	12		Beasons of the latest 8 shutdowns and hour-meter	-
4	Data on the 4th latest shutdown	12		data when the shutdowns were generated	
5	Data on the 5th latest shutdown	12		(For details, see the tables below.)	
6	Data on the 6th latest shutdown	12			
7	Data on the 7th latest shutdown	12			C
8	Data on the 8th latest shutdown	12			
CS	Check sum	2	(CS)		

Shutdown (SD) data

5

Order	Content	Length (BYTE)	Value	Remarks
1	SD category data	1		SD category (For details, see the table below.) 0 for no SD
2	SD subcategory data	1		SD subcategory (For details, see the table below.)
3	HOUR METER	7		Time when a shutdown managed by the Panel Main microcomputer was generated All digits are padded with asterisks when there was no SD.
4	Dummy	3		All digits are padded with asterisks.

■ SD categories/SD subcategories

5

SD category (response)	Reason for SD	w/wo subcategory	SD subcategory (response)	Reason for subcategory	
"0"	No SD (no abnormality)	Without subcategory	"0"		E
"5"	Shutdown signal from D-Amp.	With subsatagony	"1"	A_NG_B : L	
5	Short-circuit of speaker terminal.	With Subcategory	"2"	OTW : L	
"6"	Failure in module microcomputer communication	Without subcategory	"0"		
	Failure in IIC communication		"1"	Displayport receiver	
0		with subcategory	"2"	Failure in AUDIO PWM IC communication	
			"1"	FAN_A stop	
A	FAN Stop	with subcategory	"2"	FAN_B stop	
	Abnormal temperature of the display		"1"	High temperature at Temperature Sensor 1	
B	unit (high)	with subcategory	"2"	High temperature at Temperature Sensor 2	F
"D"	Abnormality in power of the Display MAIN Assy	With subcategory	"1"	Abnormality in 6.5V power supply.	

7

6

8

D

1 2 **6. SERVICE FACTORY MODE** 6.1 DETAILS OF THE FACTORY MENU

The Factory menu will be displayed only when the Media Receiver is connected. For details on how to enter Factory menu, refer to "6.1 DETAILS OF THE FACTORY MENU" in the service manual for the Media Receiver.

З

4

[1] PANEL FACT.

Operation Items

This is the menu screen for the adjustment of the panel. Data acquisition and value adjustment can be performed for the following items:

	2	2		
ļ		,		

А

в	No. Indication		Description of functions
	[1-1]	PANEL INFORMATION	Data, such as the version of the microcomputer of the panel, product serial number, and statuses of EEPROM for adjustment values for the main unit and for backup, are displayed.
	[1-2]	PANEL WORKS	Operation data, such as accumulated pulse-meter count, accumulated hour-meter count, accumulated power-on count, and the temperature detected by the sensor, are displayed.
	[1-3]	POWER DOWN	The power-down history is displayed.
	[1-4]	SHUT DOWN	The shutdown history of the panel section is displayed.
	[1-5]	PANEL-1 ADJ (+)	Settings of the driving voltage and AM radio prevention can be performed.
C	[1-6]	PANEL-2 ADJ (+)	White balance and ABL (power consumption) for the panel can be set.
	[1-7]	PANEL FUNCTION (+)	Setting of the panel-degradation correction-level and various functions are displayed.
	[1-8]	ETC. (+)	Copying of backup data, clearing of various settings, and changing of settings for functions for which setting data are not stored upon last update are performed.
	[1-9]	RASTER MASK SETUP (+)	The mask indication (RASTER) can be set and indicated.
	[1-10]	PATTERN MASK SETUP (+)	The mask indication (PATTERN) can be set and indicated.
	[1-11]	COMBI MASK SETUP (+)	The mask indication (COMBI) can be set and indicated.

D

Е

F

92

1

2

4

Details of indications in each layer

[1-1] PANEL INFORMATION

5

 Data, such as the version of the microcomputer of the panel, product serial number, and statuses of digital EEPROM for storing the adjustment values and for backup EEPROM, are displayed. No other layers are nested below this layer, and there are no adjustment items.



Key operation

<down></down>	: Shifting to PANEL WORKS
<up></up>	: Shifting to COMBI MASK SETUP
	(+)
<l r=""></l>	: Updating displayed information

A

В

С

Contents of the Display item

MODULE	: The version of data written in the Module microcomputer is indicated.
-PRG	: The program version of the Module microcomputer is indicated.
-DAT	: The data version of the Module microcomputer is indicated.
SEQ PRS	: The version of data written in the Sequence LSI is indicated.
-PRG	: The program version of the Sequence LSI is indicated.
-PIC	: The Picture-data version of the Sequence LSI is indicated.
-SEQ	: The sequence-data version of the Sequence LSI is indicated.
SERIAL	: The serial number of the module is indicated.
DIG.EEP	: The adjusted status of the EEPROM that is mounted on the DIGITAL Assy is indicated.
BACKUP	: The adjusted status of the EEPROM for backup that is mounted on the SENSOR Assy is indicated.

[1-2] PANEL WORKS

• Data on operations, such as the accumulated pulse-meter counts, hour-meter count, power-on count, and temperature detected by the sensor, are displayed. No other layers are nested below this layer, and there are no adjustment items.



Key operation

<down></down>	: Shifting to POWER DOWN	
<up></up>	: Shifting to PANEL INFORMATION	
<l r=""></l>	: Updating displayed information	

Temperature unit is " °C (Centigrade) ".

Contents of the Display item

5

- PM-B1 to B5: The accumulated pulse-meter counts for the 5 blocks on the screen are indicated. (the lowest-order digit represents millions of pulses.)
- HR-MTR: The hour-meter value (accumulated power-on hours) is indicated.
- P-COUNT: The accumulated power-on count is indicated.
- TEMP1: The current panel temperature and the historical maximum temperature recorded in memory are indicated. The temperature unit is " °C (Centigrade) ".
- CLS-RGB: Data obtained from the color sensor are displayed in the order R, G, and B, with the status indication at the end.

6

CLS Status	OSD Indication
Function OFF	-OFF
Color sensor module non connection	-NC
Data abnormality	-INV
Data normal	-OK

Note:

Neither the color sensor value nor the status indication will be displayed if the color sensor function is set to ON in the ETC (+) layer beforehand.

93

F

Е

KRP-500P

^A [1-3] POWER DOWN

• The power-down history is displayed. No other layers are nested below this layer.

2



Key operation

3

<down></down>	: Shifting to SHUT DOWN
<up></up>	: Shifting to PANEL WORKS
<l r=""></l>	: Updating displayed information

Contents of the Display item

С

D

Е

F

94

1

• The last most 8 power-down histories are displayed with the hour-meter values that indicate the hours when power-downs occurred.

KRP-500P

3

4

2

- When power-down is confirmed, the factor is displayed as "1st", "2nd", according to the accuracy order.
- The power-down history is not recorded when the power-down occurred at the same place and same time.

<Causes of power-down and corresponding OSD indications>

Cause of power-down	OSD Indication	Cause of power-down	OSD Indication
POWER SUPPLY Unit	P-PWR	ADDRESS Assy	ADRS
SCAN Assy	SCAN	DC/DC converter for X drive	X-DCDC
5 V power for SCAN	SCN5V	X-SUS	X-SUS
DC/DC converter for Y drive	Y-DCDC	DIG-DCDC	D-DCDC
Y-SUS	Y-SUS	Unknown	UNKNOW

[1-4] SHUT DOWN

5

• The shutdown history of panel section is displayed. No other layers are nested below this layer, and there are no adjustment items.

				1				5					10				15					20					25				30		32		
1				Ρ	Α	Ν	Е			E	Α	С	П					Π	Ν	1		3	0	6	0	2		R	G	В	J	H	В		
	AF	ŘΕΑ	1	s	н	U	П			D	0	w	Ν																						
			2					Μ	Α	П	Ν						S	U	в					0	0	0	1	2	4	н	2	3	Μ		
5			3																																
			4		1				Μ	Ρ	-	Ν	G			Π	Ν	Ρ		E				0	0	0	1	2	4	H	2	1	Μ		
			5		2			S	Q	E		s	Π			R	Π	R	Υ					0	0	0	1	1	5	H	0	5	Μ		
			6		3			Μ	D	-	D	Ε	۷			D	Α	С						0	0	0	1	0	7	н	5	3	Μ		
			7		4			S	Q			s				V	Е	R		Н	S			0	0	0	0	9	8	Н	4	7	Μ		
10			8		5			Μ	D	-	D	Ε	۷			в	Α	С	κ	U	Ρ			0	0	0	0	5	1	Н	3	0	Μ		
			9		6			S	Q			s				В	U	s	Υ					0	0	0	0	1	2	н	0	7	Μ		
			А		7																									Н			Μ		
			в		8																									Н			Μ		
			С																																
15			D											Τ	Τ																				
16			Е											Τ																					

Key operation

7

<down></down>	: Shifting to PANEL-1 ADJ (+)
<up></up>	: Shifting to POWER DOWN
<l r=""></l>	: Updating displayed information

8

А

В

С

D

Contents of the Display item

5

- The shutdown history is displayed. The last most 8 shutdown histories are displayed with the hour-meter values that indicate the hours when shutdowns occurred.
- When there is detail information when shutdown occurred, the possible defective part is displayed as Sub information.
- The shutdown history is not recorded when the shutdown occurred at the same place and same time.

6

<Cause of shutdown and corresponding OSD Indication >

Cause of shutdown	(MAIN)	Cause of shutdown (SU	IB)		
Main cause	OSD Indication	Sub cause	OSD Indication		
SQ_LSI	SQ_LSI	Communication Error	RTRY		
		Drive Stop	SQNO		
		Busy	BUSY		
		Version mismatching (H/S)	VER-HS		
		Version mismatching (H/M)	VER-HM		
		Version mismatching (H/I)	VER-HI		
		Digital EEPROM	EEPROM		
		Backup EEPROM	BACKUP		
		DAC IC	DAC		
Abnormally in RST2 power supply	RST2	-	-		
Abnormally in panel temperature		High temperature of the panel	TMP-H		
	I MP-NG	Low temperature of the panel	TMP-L		

F

KRP-500P

6

[1-5] PANEL-1 ADJ (+)

А

D 16

Е

F

96

1

This is a page for settings for the driving voltage and AM radio countermeasures. Pressing the ENTER/SET key shifts the screen to the next nested layer below for item selection.

On third line of the screen, the white balance, ABL table, and drive sequence in the current status are displayed. (Items that have lower layers are the same.)

2



E

Key operation

З

<DOWN> : Shifting to PANEL-2 ADJ (+)

- <UP> : Shifting to POWER DOWN
- <SET> : Shifting to the next nested layer

Key operation

<down></down>	: Shifting to the next item
<up></up>	: Shifting to the previous item
<right></right>	: Adding by one to the adjustment/
	setting value
<left></left>	: Subtracting by one from the
	adjustment/setting value
<vol+></vol+>	: Adding by 10 to the adjustment/
	setting value
<vol-></vol->	: Subtracting by 10 from the
	adjustment/setting value
<set></set>	: Determining the adjustment/setting
	value and shifting to the upper laye

4

When entered to this layer, panel white balance and the gamma setting become the default temporarily for setting that is necessary for voltage adjustment. Turn off the noise option function.

3

No.	Item	OSD Indication	Variable Range	Setting Value	RS-232C Command	Remarks
1	Vsus voltage	VOL SUS <=>	000 to 255	Factory	VSU	
2	Vysnofs voltage	VOL OFFSET <=>		adjustment	VOF	
3	Vyprst voltage	VOL RST P <=>		value	VRP	
4	Vxpofs1 voltage	VOL XPOFS1 <=>			VX1	
5	Vxpofs2 voltage	VOL XPOFS2 <=>			VX2	
6	Vyknofs1,2 voltage	VOL YKNOFS1 D <=>			V1F	
7	Vyknofs3 voltage	VOL YKNOFS3 D <=>]		V3F	
8	Vyknofs4 voltage	VOL YKNOFS4 D<=>			V4F	
9	∆ Vyknofs1,2/3/4	VOL YKNOFSA D<=>	1		VYF	
10	First reset (wedge width)	RESET1ST_KSB <=>	112 to 144	128	R1K	Factory use
11	Second reset (wedge width)	RESET2ND_KSB <=>			R2K	item
12	1SF - Y sus tail (wedge width)	YSTL_1SF_KSB <=>	1		Y1K	
13	1SF - Y sus tail (resonance down width)	YSTL_1SF_HZ <=>	1		Y1Z	
14	3SF and later - first X sus (resonance up width)	XSUS_1ST_B <=>			X1B	
15	2SF - second Y sus (resonance up width)	YSUS_2ND_B <=>	1		Y2B	
16	2SF - third X sus (resonance up width)	XSUS_3RD_B <=>	1		ХЗВ	
17	2SF - repeat Y sus (resonance up width)	YSUS_B <=>			YSB	
18	2SF - repeat X sus (resonance up width)	XSUS_B <=>			XSB	
19	3SF and later - Y sus tail (wedge width)	YSTL_KSB <=>	1		YTK	
20	3SF and later - Y sus tail (resonance down width)	YSTL_HZ <=>			YTZ	
21	2SF - Y sus tail (wedge width)	YSTL_2SF_KSB <=>]		Y2K] [
22	2SF - Y sus tail (resonance down width)	YSTL_2SF_HZ <=>]		Y2Z	
23	3SF and later (2 pulses of SSF) - Y sus tail (wedge width)	YSTL_FMR_KSB <=>			YNK	
24	Timing between Scan and Address	SCAN ADRS ADJ <=>	1		SAT	1
25	SUS frequency (AM radio anti-jamming)	SUS FREQ <=>	MODE1 to 8	MODE1	SFR	Note

7

8

А

Е

F

97

8

<Next nested layer of PANEL-1 ADJ (+)>

6

5

5

Note: It is necessary to turn OFF and ON the power for reflecting the setting change.

KRP-500P

7

[1-6] PANEL-2 ADJ (+)

А

• White balance of the panel can be adjusted. Pressing the ENTER/SET key shifts the screen to the next nested layer below for item selection.

3

2



No.	Item	OSD Indication	Variable Range	Setting Value	RS-232C COMMAND	Remarks
1	Panel WB R highlight	R-HIGH <=>	000 to 999	Factory	PRH	
2	Panel WB G highlight	G-HIGH <=>		adjustment	PGH	
3	Panel WB B highlight	B-HIGH <=>		value	РВН	
4	Panel WB R lowlight	R-LOW <=>	000 to 999		PRL	
5	Panel WB G lowlight	G-LOW <=>			PGL	
6	Panel WB B lowlight	B-LOW <=>			PBL	
7	ABL	ABL <=>	000 to 255		ABL	

The ABL/WB adjustment values are grouped into three tables with ABL and four tables with WB, depending on the drive sequences. The adjustment value for the actually driven table is displayed. The number of the adjustment table and the drive sequence currently selected are displayed on the right side of the third line as the On-Screen display.

	ABL Table	WB Table	OSD Indication	Drive Sequence	OSD Indication	Remarks
	TABLE 1	TABLE 1	A1W1	VIDEO-60Hz	60VS	
				PC-60Hz	60PS	
	TABLE 2	TABLE 2	A2W2	VIDEO-48Hz	48VS	
				VIDEO-50Hz	50VS	
F	TABLE 3	TABLE 3	A3W3	VIDEO-72Hz	72VS	
				VIDEO-75Hz-1	75V1	
		TABLE 4	A3W4	VIDEO-75Hz-2	75V2	Correspond to MASK indication only

KRP-500P

3

4

2

<Next nested layer of PANEL-2 ADJ (+)>

<ABL/WB adjustment table and Drive sequence>

D

[1-7] PANEL FUNCTION (+)

5

 A level setting for panel degradation correction can be made. Pressing the ENTER/SET key shifts the screen to the next nested layer below for item selection.

6



<Next nested layer of PANEL FUNCTION (+)>

No.	Item	OSD Indication	Variable Range	Setting Value	RS-232C COMMAND	Remarks	
1	R deterioration correction LEVEL	R-LEVEL <=>	Lv-10 to 7	Lv-3	RRL	Factory use	
2	G deterioration correction LEVEL	G-LEVEL <=>		Lv-2	RGL	item (Note)	
3	B deterioration correction LEVEL	B-LEVEL <=>		Lv-0	RBL		
4	L1 address	ADDRESS L1 <=>	PH0 to 9	PH2	AP0		
5	L2 address	ADDRESS L2 <=>		PH2	AP0	1	
6	L3 address	ADDRESS L3 <=>		PH3	AP1		-
7	L4 address	ADDRESS L4 <=>		PH1	AP1		
8	U1 address	ADDRESS U1 <=>		PH2	AP2	1	
9	U2 address	ADDRESS U2 <=>		PH2	AP2		
10	U3 address	ADDRESS U3 <=>		PH3	AP3		_
11	U4 address	ADDRESS U4 <=>		PH1	AP3	1	
12	Streaking correction	STK MODE <=>	OFF to MODE1 to 8	MODE1	SKM		
13	Black display mode	FULL BLACK <=>	OFF to MODE1	MODE1	FBM		
14	Panel Rx characteristic	PANEL RX <=>	000 to 999	Factory	PRX	Factory use	
15	Panel Ry characteristic	PANEL RY <=>	000 to 999	adjustment	PRY	item	
16	Panel Gx characteristic	PANEL GX <=>	000 to 999	value	PGX		-
17	Panel Gy characteristic	PANEL GY <=>	000 to 999		PGY	1	
18	Panel Bx characteristic	PANEL BX <=>	000 to 999	1	PBX		
19	Panel By characteristic	PANEL BY <=>	000 to 999	1	PBY	1	
20	Color sensor R coefficient	CLS R <=>	000 to 255	128	CSR	1	
21	Color sensor G coefficient	CLS G <=>	000 to 255	128	CSG]	.
22	Color sensor B coefficient	CLS B <=>	000 to 255	128	CSB]	

Note: It is necessary to turn OFF and ON the power for reflecting the setting change.

6

5

KRP-500P

8

А

В

С

[1-8] ETC. (+)

А

1

• Clearance of various log data for the panel and changing of settings for which setting data were not stored upon last update can be performed.

3

Pressing the ENTER/SET key shifts the screen to the next nested layer below for item selection.

2



<Next nested layer of ETC (+)>

	No.	Item	OSD Indication	Processing Contents	RS-232C COMMAND	Remarks
	1	Backup EEPROM data	BACKUP DATA <=>	NO OPRT (No operation) TRANSFER (Backup data transmission)	BCP	
	2	Digital EEPROM data	DIGITAL EEPROM <=>	 NO OPRT (No operation) REPAIR (Adjustment is complete) DELETE (Adjustment is not complete) 	FAJ/UAJ	
	3	PD history	PD INFO. <=>	NO OPRT (No operation)	CPD	
	4	SD history	SD INFO. <=>	• CLEAR (Data clear)	CSD	
E	5	HOUR METER	HR-MTR INFO. <=>		СНМ	
	6	Pulse meter	PM/B1-B5 <=>		СРМ	
	7	PON counter	P COUNT INFO. <=>		CPC	
	8	Maximum temperature	MAX TEMP. <=>		CMT	
	9	Mirror reversing display	MIRROR <=>	 Mirror reversing display OFF MODE1 (Right and left reversing) MODE2 (Top and bottom reversing) MODE3 (Right and left, Top and bottom reversing) 	MIR	The indication on the menu is also highlighted. The setting is canceled upon power-off.
F	10	Color sensor mode	CLS <=>	Color sensor operation OFF Color sensor operation ON	CSF	

KRP-500P

3

4

2

100

1

D

[1-9] RASTER MASK SETUP (+)

5

• This menu set the RASTER MASK and the drive sequence at RASTER MASK state. Pressing the ENTER/SET key shifts the screen to the next nested layer below for item selection.



• The changed sequence and the ABL/WB table are retained until the mask is turned off.

No.	Item	OSD Indication	MASK Display Sequence	RS-232C COMMAND	Remarks
1	Mask off	MASK OFF			
2	Display raster mask 01	RST MASK 01 <=>	<=>50V<=>60V<=>60P<=>	MKR/VFQ	
			72V<=>75V1<=>75V2<=>		
26	Display raster mask 25	RST MASK 25 <=>			

KRP-500P

6

<Next nested layer of RASTER MASK SETUP (+)>

5

Е

F

D

A

8

[1-10] PATTERN MASK SETUP (+)

А

• This menu set the PATTERN MASK and the drive sequence at PATTERN MASK state. Pressing the ENTER/SET key shifts the screen to the next nested layer below for item selection.

3

2



 $\,$ $\,$ $\,$ $\,$ $^{\rm o}$ The changed sequence and the ABL/WB table are retained until the mask is turned off.

<Next nested layer of PATTERN MASK SETUP (+)>

No.	Item	OSD Indication	MASK Display Sequence	RS-232C COMMAND	Remarks
1	Mask off	MASK OFF			
2	Display raster mask 01	PTN MASK 01 <=>	<=>50V<=>60V<=>60P<=>	MKS/VFQ	
			72V<=>75V1<=>75V2<=>		
50	Display raster mask 49	PTN MASK 49 <=>			

Е

F

102

3

4

[1-11] COMBI MASK SETUP (+)

5

• This menu set the COMBI MASK and the drive sequence at COMBI MASK state. Pressing the ENTER/SET key shifts the screen to the next nested layer below for item selection.



• The changed sequence and the ABL/WB table are retained until the mask is turned off.

<nex< th=""><th colspan="9"><next (+)="" combi="" layer="" mask="" nested="" of="" setup=""></next></th></nex<>	<next (+)="" combi="" layer="" mask="" nested="" of="" setup=""></next>								

5

No.	Item	OSD Indication	MASK Display Sequence	RS-232C COMMAND	Remarks
1	Mask off	MASK OFF			
2	Display raster mask 01	CMB MASK 01 <=>	<=>50V<=>60V<=>60P<=>	MKC/VFQ	
			72V<=>75V1<=>75V2<=>		
18	Display raster mask 17	CMB MASK 17 <=>			

KRP-500P

6

Е

D

А

F

103

[2] PANEL MAIN FACT.

А

В

С

D

■ Operation Items in the PANEL MAIN FACT. Menu

2

On the PANEL MAIN FACT. menu screen, acquisition of information on and settings for the display main unit can be performed, as shown in the table below:

3

No.	Indication	Description of functions
[2-1]	VERSION (3)	To indicate the versions of the microcomputers for the display (incl. those for the display main unit)
[2-2]	PM NG INFO.	To indicate the shutdown history of the display main unit
[2-3]	PM STATE INFO.	To indicate temperatures of the display main unit, state of the fans, brightness, and model information
[2-4]	DP_RX INFO.	Data on the DP receiver
[2-5]	PM_SETUP (+)	To clear the history and perform function settings whose data are not retained after the unit is turned off
[2-6]	PM_BEZEL_SETUP	To perform the bezel setup
[2-7]	PM_NG_CLEAR	To clear the shutdown history

Description of Indications on Each Layer

[2-1] VERSION (3)

The versions of the microcomputers for the display (incl. those for the display main unit) are indicated on the VERSION (3) screen. No other layers are nested below this layer, and there are no adjustment items.

Although the description on the VERSION (3) screen is included in the PANEL MAIN FACT. section, this screen actually belongs to the INFORMATION layer.

KRP-500P

3

4

2



E Contents of the Display item

- P MAIN: Version of the writing data for the Panel Main microcomputer
- MODULE: Version of the writing data for the Module microcomputer
- SEQ PRS: Version of the writing data for the sequence LSI
- DP RX: Version of the writing data for the DP receiver firmware
- DP RX HARD: Version of the hardware for the DP receiver
- PANEL INFO: Information on the display panel

1

F

[2-2] PANEL MAIN NG INFORMATION

5

The shutdown history of the display main unit is indicated on the PM NG INFO. screen. No other layers are nested below this layer.

6

					5					10					15					20					25					30		32
1	Ρ	Μ		F	Α	С	Π	0	R	Y					Π	Ν	1		3	0	1	0	1	-	Ν	Π	۷		J	Н	В	
		Ρ	Μ		Ν	G		Π	Ν	E	0																					
				Μ	Α	П	Ν					S	U	В						0	0	1	5	1	Н	2	1	Μ				
5																																
		1		Ρ	Μ	-			С			Ρ	W	Μ						0	0	0	3		H	5	0	Μ				
		2		Ρ	Μ		Π	Π	С			D	Ρ		R	Х				0	0	0	1	3	H	0	3	Μ				
		3		Ρ	-	F	Α	Ν				F	Α	Ν	1					0	0	0	0	2	H	5	2	Μ				
		4		Μ	0	D	U	L	Ε											0	0	0	0	1	H	5	8	Μ				
10		5		П	Ξ	Μ	Ρ	3				П	1							0	0	0	0	0	H	0	7	Μ				
		6																														
		7																														
		8																														
15																																
16																																
					-	-	-	-			_		-		-			_		-		_								_	_	

Key operation

7

<DOWN> : Shifting to PM STATE INFO. <L/R> : Updating displayed information

8

А

В

С

D

Contents of the Display item

5

- The last 8 shutdown logs for the display are displayed with the latest log at the top and with hour-meter values that indicate when shutdowns occurred.
- If there was detailed information when a shutdown occurred, the possible defective part is displayed as Sub information.
- The shutdown history is not recorded if the shutdown was initiated for the same reason and at the same time as the previous shutdown.

<Cause of shutdown and corresponding OSD Indication >

Cause of shutdown	(MAIN)	Cause of shutdown (SUB)						
Main cause	OSD Indication	Sub cause	OSD Indication					
D-Amp/Short-circuiting of the	AUDIO	A_NG	AUDIO					
speakers		OTW	OTW					
Module microcomputer	MODULE	-						
IIC communication of the Panel	PM-IIC	DP_Rx	DP_Rx					
Main microcomputer		PWM_Processor	PWM					
Abnormality in the fans	P-FAN	FAN_NG_A="H"	FAN1					
		FAN_NG_B="H"	FAN2					
High temperature of the display unit	TEMP3	High temperature at Temperature Sensor 1	T1					
riigh temperature of the display unit		High temperature at Temperature Sensor 2	T2					
Power supply of the POWER SUPPLY Unit	MB-POW	VCC power decreaseof the MAIN Assy	RELAY					

Е

F

KRP-500P

6

105

[2-3] PANEL MAIN STATE INFORMATION

The display (unit) temperatures detected by the temperature sensors, FAN rotating status, the value acquired by the Room Light Sensor, and settings for the model are indicated. No other layers are nested below this layer.



Key operation

З

<down></down>	: Shifting to DP_RX INFO.	
<up></up>	: Shifting to PM NG INFO.	

<L/R> : Updating displayed information

Contents of the Display item

• TEMP1: The current display (panel) temperature is indicated. Temperature is in °C (Centigrade).

2

• TEMP3, T1-T2, T3 (reserved): The current display (unit) temperature is indicated. Temperature is in °C (Centigrade).

KRP-500P

3

2

- FAN A, B: Controlled state of the fans (HIGH, LOW, STOP), D/A value
- B-SENSOR: A/D value of the Room Light Sensor
- MODEL INFO.: Model information, such as setup status of the bezel

D

A

В

С

[2-4] DP-RX INFORMATION

This screen is for use by engineers. No other layers are nested below this layer.



Key operation

<down></down>	: Shifting to PM_SE	TUP (+)
---------------	---------------------	---------

<UP> : Shifting to PM STATE INFO.

<L/R> : Updating displayed information

4

1

F

[2-5] PANEL MAIN SETUP (+)

5

The shutdown logs can be cleared, and temporary settings for functions that you do not wish to retain after the unit is turned off can be performed. Pressing the ENTER/SET key shifts the screen to the next nested layer below for item selection.

6



<Next nested layer of PANEL MAIN SETUP (+)>

5

No.	Item	OSD Indication	Content	RS-232C COMMAND	Remarks	
1	Bezel setting	PM_BEZEL_SETUP <=>	 NO OPRT (No operation) R1 (Bezel setting 1) Black KRP-500P/WYSIXK5, WYS5, LFT, WA5 R2 (Bezel setting 2) White No use R3 (Bezel setting 3) Beige No use EP (For use by engineers) 	BZS		E
2	SD history clear (panel main)	PM NG CLEAR <=>	 NO OPRT (No operation) CLEAR (Clearance of data) 	CAL		

KRP-500P

6

F

8

А

В

С

D

[2-6] PANEL MAIN BEZEL SETUP

Setup of the bezel can be performed on the PANEL MAIN BEZEL SETUP screen.

- Without the Panel Main Bezel setup, detection by the Room Light Sensor will not be performed properly.
- Even if Final setup (in System Operation mode [FSTS35] or in Display Standalone Operation mode [FSP]) is performed, the initial value (R1) will not be restored.



Key operation

- <DOWN> : Shifting to the next item
- <UP> : Shifting to the previous item
- <RIGHT> : Changing the setting value upward (+)
- <LEFT> : Changing the setting value upward (-) <ENTER/SET> : Determining the changed value and return to the layer above

4

Select the bezel setup setting, using the L or R key, then press the SET key to determine the setting. When NO OPT is selected, bezel setup is not performed.

^C Each time the L or R key is pressed, setup settings are changed, as shown below: $ightarrow R1 \leftrightarrow R2 \leftrightarrow R3 \leftrightarrow EP \leftrightarrow NO \text{ OPT} \leftarrow$

"NO OPT" is selected immediately after the PANEL MAIN BEZEL SETUP screen is displayed.

R1: The bezel setup is performed according to ROM table 01. (Default)
R2: The bezel setup is performed according to ROM table 02.
R3: The bezel setup is performed according to ROM table 03.
EP: The bezel setup is performed according to the EEPROM table. (For use by engineers)
NO OPT: Bezel setup is not performed.

D

Α

В

[2-7] PANEL MAIN NG CLEAR

The shutdown logs can be cleared on the PM NG CLEAR screen.



"NG CLEAR" denotes clearing of the SD logs managed by the Panel Main microcomputer.

Select the setting, using the L or R key, then press the ENTER/SET key to clear the data. When NO OPT is selected, NG CLEAR is not performed.

Pressing the L or R key toggles between CLEAR and NO OPT, as shown below:

CLEAR 🕶 NO OPT

108 KRP-500P
7. DISASSEMBLY 7.1 FLOWCHART OF REMOVAL ORDER

Note: Even if the unit shown in the photos and illustrations in this manual may differ from your product, the procedures described here are common.

7

8

А

Flowchart of removal order for the main parts and boards

It is efficient to proceed with removal of the main parts and boards in the order shown in the chart below:



7.2 DISASSEMBLY

2

1

Disassembly

А



3



Notes on Lead Dressing

A

D

Е

Note: The wiring shown in the photo is different from the actual wiring, because the product in the photo is a prototype. Upon servicing, be sure to restore the original wiring of the unit after repair work.

3



Notes on Removing the POWER SUPPLY Unit

Discharge of residual electric charge

Immediately after the power cord is unplugged, residual electric charge remains for about 3-5 minutes in the capacitor inside the POWER SUPPLY Unit.

Before removing the POWER SUPPLY Unit, make sure that residual electric charge has fallen to a safe level.

How to discharge residual electric charge rapidly

Discharge residual electric charge by connecting two 220 Ω (10 W) forced discharging resistors (440 Ω in total,) one to each end, of C101.

<How to remove the POWER SUPPLY Unit>

① Make sure that the power cord is unplugged. Check the voltage of both ends of C101, using a tester.

2

- 2 Wait until the voltage at both ends of C101 has fallen to 5 V or less.
- ③ When the voltage becomes less than 5 V, disconnect the connectors of the POWER SUPPLY Unit then remove it.

POWER SUPPLY Unit



Points of checking residual electric charges: After making sure that the voltage of both ends of C101 has fallen to 5 V or less, remove the POWER SUPPLY Unit.

KRP-500P

3



2 MAIN and AUDIO Assys Note: The wiring shown in the photo is different from the actual wiring, because the product in the photo is a prototype. Upon servicing, be sure to restore the original wiring of the unit after repair work. • Under cover (509M) (1) Remove the six N grip screws. (ABA1381) (2) Remove the three screws. (ABA1389) (3) Remove the under cover (509M). 1 ⊚(1) Under cover (509M) Screw tightening order The other screws are random order. Terminal panel SEP (1) Remove the two screws. (BPZ30P080FTB) Note: Do not use an electric screwdriver. (2) Remove the one screw. (AMZ30P060FTB) If the screw is over-tightened, the screw thread (3) Remove the one screw. (BMZ30P060FTB) may be damaged. Terminal panel SEP (4) Remove the two hexagon headed screws. (ABA1382) (5) Remove the two N grip screws. (5) (ABA1381)(KRP-500P/WYSIXK5) Remove the two screws. (AMZ30P060FTB)(KRP-500P/WYS5, LFT, WA5) (6) Remove the two N grip screws. (ABA1381) Terminal panel SEP (7) Remove the three N grip screws. (ABA1381) (8) Remove the two screws. (ABZ30P080FTC) (9) Remove the terminal panel SEP. (8) Screw tightening order The other screws are random order.

KRP-500P

5

113

8

A

В

С

D

Е



Note: The wiring shown in the photo is different f Upon servicing, be sure to restore the orig	rom the actual wiring, because the product in the photo is a prototype. inal wiring of the unit after repair work.
Note: When you remove whole Multibase Section, it is not necessary to remove terminal panel SEP. (1) Remove the four screws. (ABZ30P080FTC) (2) Disconnect the two flexible cables.	
(3) Lift the multi base section to the direction of the arrow.	
• Screw tightening order	

5

6

7

8

А

В

С

D

Е

F



7

6



5 Access to 50F ADDRESS L and S Assys

6

• Sub frame L and R Assy (509)

5

5

(1) Remove the 16 screws. (TBZ40P060FTC)

(2) Disconnect cables, connectors, as requied.

(3) Remove the sub frame L and R Assys (509).



7

8

А

D

Е

F



KRP-500P

6







8. EACH SETTING AND ADJUSTMENT

- At shipment, the unit is adjusted to its best conditions. Normally, it is not necessary to readjust even if an assembly is replaced. If the adjustment is shifted or if it becomes necessary to readjust because of part replacement, etc., perform the adjustment as described below.
 Any value changed in Service/Factory mode will be stored in memory as soon as it is changed. Before readjustment, take note of the
- original values for reference in case you need to restore the original settings.
- 3. Use a stable AC power supply.

Α

8.1 ADJUSTMENT REQUIRED WHEN THE UNIT IS REPAIRED OR REPLACED

B When any of the following assemblies is replaced

	POWER SUPPLY Unit	Refer to "8.3 HOW TO CLEAR HISTORY DATA" .
	DIGITAL Assy	Writing of backup data is required. Refer to the "8.2 BACKUP OF THE EEPROM (DIGITAL ASSY)".
	X DRIVE Assy	No adjustment required
с	Y DRIVE Assy	No adjustment required
	Service Panel Assy	Refer to "8.3 HOW TO CLEAR HISTORY DATA" and "8.4 ADJUSTMENTS WHEN THE SERVICE PANEL ASSY IS REPLACED".
	MAIN Assy (Note)	No adjustment required
	AUDIO Assy	No adjustment required
D	SENSOR Assy	Writing of backup data is required. Refer to the "8.2 BACKUP OF THE EEPROM (DIGITAL ASSY)".
	Other assemblies	No adjustment required

Е

Note: After replacing the MAIN Assy, be sure to perform the FINAL SETUP. To perform the FINAL SETUP for the display main unit and module via the RS-232C connector on the display, set the unit to Standalone Operation mode, by issuing the SYSS00 command, then issue the FAY command then FSP command. (Common to models of any size and for any destination) To perform the FINAL SETUP of the entire system, i.e., the display and the Media Receiver (MR), input commands via the RS-232C connector on the MR in System Operation mode. For details, refer to the service manual of the Media Receiver.

KRP-500P

3

4

2

When any of the following parts is replaced

Notes on replacing parts

5

5

For the parts described in the list below, replacement is required for the whole Assy, not only the defective part. If any part listed below is identified as defective and needs replacement, replace the whole Assy, and make necessary adjustments after replacement.

7

8

А

В

6

		Parts that Require Whole-Assy Replacement				
PCB Assy No.	Assy Name	Ref No.	Function Name	Part No.		
۵\\\\/2550		IC3302	Flash ROM	AGC1096		
AWV2555	DIGITAL ASSy	IC3601	Flash UCOM	AGC1095		
AWV2599	X DRIVE Assy	Parts of X D-E	Parts of X D-D CON BLOCK			
AWV2600	Y DRIVE Assy	 Parts of Y VF D-D CON BLOCK 1 Parts of Y MAIN D-D CON BLOCK 1 Parts of Y MAIN D-D CON BLOCK 2 				
		IC5001	Display port Rx IC	GM68020H-CG-K		
		IC5003	EEPROM	S25FL016A0LMF013		
AWW1393	MAIN Assy	IC5005	EEPROM	M2404HEPROM		
		IC7001	Flash UCOM	MB91F356B-G-SPE1-K		
		IC7003	EEPROM	BR24L02FJ-W		

Reason: The whole Assy must be replaced, because adjustments and data rewriting for the Assy at the level of production C line are required.

For the parts described in the table below, replacement of individual parts is difficult, because a heat pad is provided under the bottom of the ICs.

			Parts that Replace	ment is Possible	
PCB Assy No.	Assy Name	Ref No.	Function Name	Part No.	
		IC4501	Regulator IC	NJM2871BF05	
		IC4503	Regulator IC	PQ025ENA1ZPH	D
AWW1393	MAIN Assy	IC4504	Regulator IC	NJM2846DL3-18	
		IC7004	Regulator IC	NJM2846DL3-33	
A\\A/14.000		IC8331	Regulator IC	NJM2846DL3-33	
AVV VV 1398	AUDIO ASSy	IC8401	Digital Amp	TAS5122DCA	
		IC1201	Regulator IC	PQ200WNA1ZPH	
AWW1394	FAN Assy	IC1202	Regulator IC	PQ200WNA1ZPH	

Е

F

KRP-500P

7

6

121

	POWER SUPPLY Unit		The assembly must be replaced as a unit, and no part replacement is allowed.
	MAIN Assy		No adjustment required
	AUDIO Assy	-	No adjustment required
В	DIGITAL Assy		No adjustment required
	X DRIVE Assy		No adjustment is required after replacement of parts other than those shown in "8.5 ADJUSTMENT WHEN THE DRIVE ASSYS ARE REPLACED.
	Y DRIVE Assy	-	No adjustment is required after replacement of parts other than those shown in "8.5 ADJUSTMENT WHEN THE DRIVE ASSYS ARE REPLACED.
С	ADDRESS Assy		No adjustment required
	SENSOR Assy		No adjustment required
	Other assemblies		No adjustment required

KRP-500P

2

3

4

_

3

4

2

1

А

D

Е

F

122

8.2 BACKUP OF THE EEPROM (DIGITAL ASSY)

Outline

Adjustment data are stored in the EEPROM on the DIGITAL Assy in the production process. Those adjustment data are also automatically stored in the EEPROM (for backup) on the SENSOR Assy.

If the DIGITAL Assy is replaced, those adjustment data for backup can be copied from the EEPROM on the SENSOR Assy to a new DIGITAL Assy.

Backed up data

- Drive voltage adjustment value
- Panel white balance adjustment value
- Drive waveform adjustment value
- Hour-meter count

Pulse-meter count

А

в

С

D

Е

F

- P-ON counter value
- Serial No.
- PD/SD histories

How to copy backup data

1. When the DIGITAL Assy is replaced with one for service (usual service)

Immediately after the DIGITAL Assy is replaced, the EEPROM on the DIGITAL Assy is in the status "adjustment not completed," and the EEPROM for backup on the SENSOR Assy is in the status "adjustment completed." The LED on the main unit warns you that the adjustment data in the EEPROM for backup have not been copied to the EEPROM on the DIGITAL Assy, by lighting the red LED and flashing the blue LED. In such a case, the adjustment data for backup can be used by copying the data to the EEPROM on the DIGITAL Assy, with the following procedures:



- ③ Display the PANEL INFORMATION page, then check if "NO DATA!" is set for "DIG. EEP" and "ADJUSTED" is set for "BACKUP".
- ④ Copy the backup data, as shown in the figure below.



(5) Check if "ADJUSTED" is set for "DIG. EEP" on the PANEL INFORMATION page.

6 Turn off the power.

(2) Copying, using the RS-232C commands

- ① Turn on the power.
- ② Issue the FAY command.
- With the QS2 command, confirm that the main unit adjustment flag is "adjustment not completed" and that the adjustment backup flag is "adjustment completed."
- ④ Issue the BCP command to transfer the data stored in the EEPROM for backup.
- (5) With the QS2 command, confirm that the main unit adjustment flag becomes "adjustment completed."
- (6) Turn off the power.
- **Note:** If both the DIGITAL and SENSOR Assys are to be replaced, replace the SENSOR Assy first in order to store the backup data. Then turn the unit on then back off again, then replace the DIGITAL Assy.

			KRP-500P			123
•	5	6		7	8	

2. When manual adjustment is required after the DIGITAL Assy is replaced with one for service

If backup data cannot be transferred to the DIGITAL Assy because of defective parts, etc., after the DIGITAL Assy is replaced and manual adjustment is performed, those manually adjusted data can be registered as adjusted data with the following procedures. Once the data on the DIGITAL Assy are registered as adjusted data, the adjustment data for backup will be automatically updated each time the unit is turned off. Therefore, if a DIGITAL Assy with adjusted data is mounted on the unit, the following procedures are not required, even after manual adjustment.

3

(1) Copying, using the Factory menu

① Turn on the power.

A

в

- ② Enter the Panel Factory mode.
- ③ Display the PANEL INFORMATION page, then check if "NO DATA!" is set for "DIG. EEP".

2

(4) Register the changed adjustment data as adjusted data, as described for the following procedures, then transfer them as backup data.



(5) Check if "ADJUSTED" is set for "DIG. EEP" on the PANEL INFORMATION page.(6) Turn off the power.

(2) Copying, using the RS-232C commands

- 1) Turn on the power.
- 2 Issue the FAY command.
- ③ With the QS2 command, confirm that the main unit adjustment flag is "adjustment not completed."

2

- ④ Issue the FAJ command to register the changed adjustment data as adjusted data then transfer them as backup data.
- (5) With the QS2 command, confirm that the main unit adjustment flag becomes "adjustment completed."
- E 6 Turn off the power.

1

124

KRP-500P

3. When a secondhand DIGITAL Assy is to be reused

A DIGITAL Assy in good condition that had been mounted in another product can be reused. Before reuse, by following the procedures described below, make the data in the EEPROM on the DIGITAL Assy "adjustment not completed" data in order to prevent accidental updating of backup data when the secondhand DIGITAL Assy is mounted in another product

(1) Copying, using the Factory menu

① Turn on the power.

5

- ② Enter the Panel Factory mode.
- ③ Display the PANEL INFORMATION page, then check if "ADJUSTED" is set for "DIG. EEP".

6

④ Make the data in the EEPROM on the DIGITAL Assy "adjustment not completed" data, by following the procedures below:



(5) Check if "NO DATA!" is set for "DIG. EEP" on the PANEL INFORMATION page.

(6) Turn off the power.

(2) Copying, using the RS-232C commands

- 1 Turn on the power.
- ② Issue the FAY command.

5

③ With the QS2 command, confirm that the main unit adjustment flag is "adjustment completed."

④ Issue the UAJ command to make the data in the EEPROM on the DIGITAL Assy "adjustment not completed" data.

(5) With the QS2 command, confirm that the main unit adjustment flag becomes "adjustment not completed."

- 6 Turn off the power.
- **Note:** If you mount a secondhand Assy to the product without performing the above procedures, the adjustment data and logs for the main unit specific to the product will be erased, and those of the secondhand Assy will be copied when the unit is turned off.

KRP-500P

125

8

А

В

С

D

Е

8.3 HOW TO CLEAR HISTORY DATA

Clearance of various logs after the Assys are replaced

2

Besides adjustment data, data on accumulated power-on time and logs on defective parts of the product are backed up. Some of those data must be cleared after the Assys are replaced for service. Clearance of those data can be performed in the ETC layer of the Factory menu or with RS232C commands.

З

			Cleari	ng at the Replacer	Clearing method		
	Item Content		Panel	POWER SUPPLY Unit	Other parts	Factory Menu (ETC layer)	RS-232C Commands
	Hour-meter	Accumulated power-on time	Must be cleared	No need to be cleared	No need to be cleared	HR-MTR INFO.	СНМ
в	Pulse-meter	Accumulated number of pulses emitted	Must be cleared (mandatory)	No need to be cleared	No need to be cleared	PM/B1-B5	СРМ
	Shutdown history of the panel	Causes and hour-meter values for the last eight shutdowns (SD) of the Panel	Must be cleared	No need to be cleared	No need to be cleared	SD INFO.	CSD
	Power-down history	Causes and hour-meter values for the last eight power-downs (PDs) of the Panel	Must be cleared	No need to be cleared	No need to be cleared	PD INFO.	CPD
	Power-on counter	Relay-on count	No need to be cleared	Must be cleared (mandatory)	No need to be cleared	P COUNT INFO.	CPC
	MAX TEMP	Historical max. temperature of the panel	Must be cleared	Must be cleared	Must be cleared	MAX TEMP.	СМТ

Notes: • As the pulse-meter count is used for each correction function, the log must be cleared when the panel is replaced.

 After you clear the log, the unit must be turned off then back on again to reflect the cleared data for each correction function. If any adjustment is required after clearing the log, be sure to turn the unit off then back on again before adjustment.

(1) Clearance of logs, using the Factory menu

① Turn on the power.

A

С

② Enter the Panel Factory mode.

③ Clear the various logs, as shown in the figure below.

Note: The following example shows how to clear the PD log (PD INFO.). To clear other items, select each item you wish to clear then perform the same procedures.



8.4 ADJUSTMENT WHEN THE SERVICE PANEL ASSY IS REPLACED

After the panel is replaced with one for service, voltage margin adjustment is required.

[Preparation]

Basically, voltage margin adjustment is performed using the Panel Factory menu. After the panel is replaced and the unit is turned on, clear the pulse meter first. For details on how to clear the pulse meter, see "8.3 HOW TO CLEAR HISTORY DATA".

- *1: As various corrections are made referring to the pulse-meter count to calculate how long the panel has been used, if adjustment of the panel for service is performed without clearing the pulse-meter count, proper adjustments will not be performed.
- *2: The drive sequence for Video 60-Hz is used for adjustment. When adjustment is made using the Panel Factory menu, the current drive sequence is displayed on the screen, as shown in the figure below. Make sure that 60VS is always indicated during adjustment.
- *3: Select the input fuction excepting PC.



Example of the On-Screen display during Panel Factory mode

[Supplement]

5

In the "PANEL-1ADJ" layer, the Panel White Balance value is reset to default, Panel Gamma is set to Straight, Noise is set to OFF, LUT mode is set to ON and Reset active control is set to OFF.

If adjustment is performed using RS232C commands, unlike the case of Factory menu operation, adjustments are not interlocked. Therefore, settings must be performed individually, by issuing commands. (See the section on preparations before adjustment.)



F

А

В

KRP-500P



З

rocedures for resetting prrections for change /er time	,	
Turn the unit on. / [PON]		
Enter Factory mode. / [FAY]	,	
Set PM/B1-B5 to CLEAR (to cl	ear the pulse meter). / [CPM]	
Set HR-MTR to CLEAR (to clear	ar the hour meter). / [CHM]	
Turn the unit off. / [POF]	,	
rocedures for stabilizing the anel before adjustment		 * To reflect the results of log clearing for each correction function the unit must be turned off then back on again. Before adjust- ment, be sure to turn the unit off then back on again.
Turn the unit on. / [PON]		
Enter Factory mode. / [FAY]		
Enter the tentative setting value	e of the replacement panel	Indication example of the adjustment label of service panel
VOL SUS / [VSU ***] VOL OFFSET / [VOF ***] VOL RST P / [VRP ***] VOL XPOFS1 / [VX1 ***] VOL XPOFS2 / [VX2 ***] VOL YNOFS3 D / [V1F ***] VOL YNOFS3 D / [V4F ***] VOL YNOFSA D / [VYF ***]	VOF indication value VRP indication value 085 063 V1F indication value V3F indication value +0 V4F indication value 128	VRP=018 V1F=138 V3F=128+α V4F=149 Hour MeterH Data 08/02/28 Chassis CXX99999 Time 18:27 Pnl FD4A0808100123 Note: The symbol "α" denotes the adjustment value plus 0. * Each setting value described on the adjustment label
Display CMB MASK 01 (movin	g ramp). / [MKC S01]	Therefore, just enter the data value as a setting value.
Select Video 60-Hz sequence.	/ [VFQ S03]	* To store the VFQ S03 command in memory, transmit it after
Perform aging for 30 minutes	,	
[To the Main f	flowchart (1)]	
ote: When you perform the adjustmer f the unit is shut down in the mic	nt with RS232C commands, issue th Idle of performing the adjustment flo	e following commands in addition. wchart, reissuing of the command is required.
[PAV S00] : To set panel [VFQ S03] : To set Driving [SQM S01] : To set Driving [WBI S01] : To set the generation of the set	el drive mode to Factory e Sequence to Video 60-Hz e Sequence to Video arily reset the Panel WB adjustm gamma R value to that for Factor	ent value to default (WBI S00 cancels this setting.) ry mode ry mode

KRP-500P

Main flowchart (1)...Checking VOL OFFSET

A



З

KRP-500P



7

8

Note:

5

Make sure that the following values become the final setting values.VOL SUS *1VOL XPOSF2 *1VOL OFFSETVOL YNOFS1 D *1VOL RST P *1VOL YNOFS3 D *1VOL XPOFS1 *1VOL YNOFS4 D *1VOL YNOFS4 AVOL YNOFS4 A

*1: The tentative setting value becomes the final value.

5

KRP-500P

6

131

8

Е

Recovery flowchart (1-1)...Changing the VOL OFFSET setting

з

4



[From the Main flowchart (1)]

1

A

KRP-500P

3

4

2

132

1

Recovery flowchart (1-2)...Changing the VOL OFFSET setting

6

7

8

А

в

С

D

Е

F

133



Recovery flowchart (2-1)...Changing the VOL YNOFSA D setting





7

8

А

в

С

D

Е

F

[To the Main flowchart (2)]

5

5

KRP-500P

6

135

8.5 ADJUSTMENT WHEN THE DRIVE ASSYS ARE REPLACED

Waveform adjustments required when replacing the following parts of the X DRIVE and Y DRIVE Assys.

4

Assy Name	Ref No.	Part Name	Part Category	Remarks
X DRIVE Assy	IC1101	PS9818-1(P)	Photo Coupler	
	IC1104	TND307TD	FET Driver	
	IC1204	PS9818-2(P)	Photo Coupler	
	IC1209	TND307TD	FET Driver	
Y DRIVE Assy	IC2101	PS9818-1(P)	Photo Coupler	
	IC2103	TND307TD	FET Driver	
	IC2201	PS9818-1(P)	Photo Coupler	
	IC2203	TND307TD	FET Driver	

TIME LAG ADJUSTMENT OF THE CONTROL SIGNAL (SUS-B)

① Measure the time lag for the SUS-U signal to the SUS-B signal.

② Check the time lag for the SUS-B Gate signal to the SUS-U Gate siganl.

Adjust the variable control so that the time lag of Gate becomes " time lag of input signal + $\alpha \pm 5$ nsec." **Note:** • Be sure to set the Drive to OFF for adjustment.

• For details on measuring points of waveform, see the figure below.



Time lag of SUS-U Gate and SUS-B Gate : Δ **Tsus - gub** Adjust so that " Δ **Tsus -** gub = Δ **Tsus -** iub + $\alpha \pm 5$ nsec," using the variable

Adjust so that " Δ I sus - gub = Δ I sus - lub + $\alpha \pm 5$ nsec," using the variable controls shown in the table below:

Assy	VR	Value of α
X DRIVE Assy	VR1002	60 nsec
Y DRIVE Assy	VR2002	60 nsec

2

4

136

1

F

A

В

DELAY ADJUSTMENT OF THE CONTROL SIGNAL (SUS-D)

6

1 Measure the pulse width of the SUS-D signal.

5

5

(2) Check the pulse width of the SUS-D input signal (gate terminal of Q2111).

Adjust the variable control so that the pulse width of the SUS-D input signal (gate terminal of Q2111) becomes the same pulse width \pm 5 nsec as the SUS-D signal.

Note: • For details on measuring points of waveform, see the figure below.



7

8

А

D

Е

F

137

8

SUS-D pulse width: Tsus - Dg Adjust so that "Tsus - Dg = Tsus - D \pm 5 nsec," using the variable control shown in the table below:

Assy	VR
Y DRIVE Assy	VR2001



А



KRP-500P

IGBT

Ó TP2116

			KRP-500P				139
5	-	6		7	-	8	

8

А

в

С

D

Е

F

6

5

9. EXPLODED VIEWS AND PARTS LIST

NOTES: • Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.

- The \triangle mark found on some component parts indicates the importance of the safety factor of the part.
- Therefore, when replacing, be sure to use parts of identical designation.
- Screws adjacent to ▼ mark on product are used for disassembly.
 For the applying amount of lubricants or glue, follow the instructions in this manual.
- (In the case of no amount instructions, apply as you think it appropriate.)

■ 9.1 PACKING SECTION (KRP-500P/WYSIXK5)

А



∎ P 5 6

PACKING SECTION PARTS LIS	ST (KRP-500P/WYSIXK5)
---------------------------	-----------------------

7

8

А

В

С

D

Е

F

PACKING SECTION PARTS LIST (KRP-500P				
<u>Mark</u>	<u>No.</u>	Description	Part No.	
\triangle	1	System Cable (2.9 m)	ADF1041	
\triangle	2	Power Cable	ADG1214	
\triangle	3	Power Cable	ADG1223	
	4	Remote Control Unit	AXD1562	
	5	Battery Cover (Black)	AZN2784	
NSP	6	Alkaline Dry Cell Battery (LR6, AA)	VEM1045	
	7	Binder Assy	AEC2158	
	8	Cable Guide	AEC2167	
	9	Cleaning Cloth	AED1285	
⚠	10	Ferrite Core (L5313)	ATX1039	
	11	Color Sensor Module	AXF1196	
	12	Ferrite Core (L5320)	CTX1089	
	13	Operating Instructions	ARC1609	
		(Italian / Dutch / Spanish / Rus	ssian)	
	14	Operating Instructions	ARE1494	
		(English / French / German)		
	15	Caution Card	ARM1310	
	16	Cleaning Caution PTK	ARM1311	
	17	Ferrite Core Info.	ARM1396	
	18	Block Diagram (500P)	ARY1216	
NSP	19	Warranty Card EU	ARY7129	
NSP	20	Vinyl Pouch	AHG-195	
	21	Vinyl Bag	AHG1337	
NSP	22	Vinyl Bag	AHG1340	
	23	Accessory Box	AHC1122	
	24	Power Cord Lid (50M E)	AHC1127	
	25	Pad (5095E T-L)	AHA2767	
	26	Pad (5095E T-R)	AHA2768	
	27	Pad (5095E T-C)	AHA2769	
	28	Pad (5095E B-L)	AHA2770	
	29	Pad (5095E B-R)	AHA2771	
	30	Carton Board (50M EU)	AHB1317	
	31	Upper Carton (50P EU)	AHD3733	
	32	Under Carton (5090)	AHD3672	
	33	Mirror Mat	AHG1284	
	34	HD Sheet	AHG1416	
NSP	35	Power Button Info.	ARM1428	

5

6

7

141

8

_

9.2 PACKING SECTION (KRP-500P/WYS5)



KRP-500P

А

PACKING SECTION PARTS LIST (KRP-500P/WYS5)

7

8

А

В

С

D

Е

F

-

FACI		a Section PARTS LIS	1 (KHF-300F)
<u>Mark</u>	<u>No.</u>	Description	Part No.
\triangle	1	System Cable (2.9 m)	ADF1041
\triangle	2	Power Cable	ADG1214
\triangle	3	Power Cable	ADG1223
	4	Remote Control Unit	AXD1562
	5	Battery Cover (Black)	AZN2784
NSP	6	Alkaline Dry Cell Battery	VEM1045
		(LR6, AA)	
	7	Binder Assy	AEC2158
	8	Cable Guide	AEC2167
	9	Cleaning Cloth	AED1285
⚠	10	Ferrite Core (L5313)	ATX1039
	11	Color Sensor Module	AXF1196
	12	Ferrite Core (L5320)	CTX1089
	13	Operating Instructions (Russian)	ARC1619
	14	••••	
	15	Caution Card	ARM1232
	16	Cleaning Caution 11L	ARM1283
	17	Ferrite Core Info.	ARM1395
	18	••••	
NSP	19	Warranty Card EU	ARY7127
NSP	20	Vinyl Pouch	AHG-195
	21	Vinyl Bag	AHG1337
NSP	22	Vinyl Bag	AHG1340
	23	Accessory Box	AHC1083
	24	Power Cord Lid (50M G)	AHC1128
	25	Pad (5095 T-L)	AHA2772
	26	Pad (5095 T-R)	AHA2773
	27	Pad (5095 T-C)	AHA2774
	28	Pad (5095 B-L)	AHA2775
	29	Pad (5095 B-R)	AHA2776
	30	Carton Board (50M JJ)	AHB1318
	31	Upper Carton (50P EUJ)	AHD3734
	32	Under Carton (5090)	AHD3673
	33	Mirror Mat	AHG1284
NSP	34	Power Button Info.	ARM1429

5

KRP-500P

7

6

143

9.3 PACKING SECTION (KRP-500P/LFT)

А



KRP-500P
• 5 • 6 PACKING SECTION PARTS LIST (KRP-500P/LFT)

<u>Mark</u>	<u>No.</u>	Description	Part No.
⚠NS	P 1	Power Cable	ADG1232
∕!\ NS	P2	Power Cable	ADG1234
∕!\ NS	РЗ	Power Cable	ADG1236
∕!\ NS	P4	Power Cable	ADG1239
∕∆ NS	P5	Power Cable	ADG1241
⚠́NS	P6	Power Cable	ADG1243
∕!\ NS	P7	Power Cable	ADG1244
∕∆ NS	P8	Power Cable	ADG1246
\triangle NS	Ρ9	Power Cable	ADG1251
⚠ NS	P10	Power Cord Assy	AWX1095
⚠	11	Cord Set	AXY1194
\triangle	12	System Cable (2.9 m)	ADF1041
	13	Remote Control Unit	AXD1567
	14	Battery Cover (Black)	AZN2784
NSP	15	Dry Cell Battery (R6, AA)	VEM1039
	16	Binder Assy	AEC2158
	17	Cleaning Cloth	AED1285
\triangle	18	Ferrite Core (L5313)	ATX1039
	19	Operating Instructions	ARE1495
		(English / Spanish / Portugues	e / Trad-Chinese)
	20	Caution Card	ARM1232
	21	Cleaning Caution 11L	ARM1283
	22	••••	
NSP	23	Vinyl Pouch	AHG-195
	24	Vinyl Bag	AHG1337
NSP	25	Vinyl Bag	AHG1340
	26	Accessory Box	AHC1083
	27	Power Cord Lid (50M G)	AHC1128
	28	Pad (5095 T-L)	AHA2772
	29	Pad (5095 T-R)	AHA2773
	30	Pad (5095 T-C)	AHA2774
	31	Pad (5095 B-L)	AHA2775
	32	Pad (5095 B-R)	AHA2776
	33	Carton Board (50M JJ GE)	AHB1318
	34	Upper Carton (50P GJ)	AHD3735
	35	Under Carton (5090)	AHD3673
	36	Mirror Mat	AHG1284
NSP	37	Power Button Info.	ARM1430

5

7

6

7

8

А

В

С

D

Е

F

9.4 PACKING SECTION (KRP-500P/WA5)

А





F

		5	6
PAC	CINC	G SECTION PARTS LIS	T (KRP-500
<u>Mark</u>	<u>No.</u>	Description	Part No.
\triangle	1	System Cable (2.9 m)	ADF1041
\triangle	2	AC Power Cord	ADG1209
	3	••••	
	4	Remote Control Unit	AXD1569
	5	Battery Cover (Black)	AZN2784
NSP	6	Dry Cell Battery (R6, AA)	VEM1031
	7	Binder Assy	AEC2158
	8	••••	
	9	Cleaning Cloth	AED1285
\triangle	10	Ferrite Core (L5321)	ATX1039
	11	••••	
	12	••••	
	13	Operating Instructions (Simp-Chinese)	ARC1610
	14	••••	
	15	Caution Card (PC)	ARM1302
	16	Cleaning Caution 11L	ARM1283
	17	•••••	
	18	•••••	
NSP	19	Warranty Card	ARY1161
	20	••••	
	21	Vinyl Bag	AHG1336
NSP	22	Vinyl Bag	AHG1340
	23	Accessory Box	AHC1083
	24	••••	
	25	Pad (5095 T-L)	AHA2772
	26	Pad (5095 T-R)	AHA2773
	27	Pad (5095 T-C)	AHA2774
	28	Pad (5095 B-L)	AHA2775
	29	Pad (5095 B-R)	AHA2776
	20	Corton Boord (FOM 11)	
	30	Carton Board (50M JJ)	AHB1318
	31	Upper Carton (50P C)	AHD3737
	32	Under Carton (5090)	AHD3673
	33	Mirror Mat	AHG1284
	34	Nylon Binder	AEC-093

NSP 35 Power Button Info. ARM1431

5

6

7

8

А

в

С

D

Е

F

9.5 REAR SECTION



	5	6	7	8	
(1) REA	R SECTION PARTS LIS	т			
Mark No.	Description	Part No.			
1	POW SW Assy	AWW1395			
2	••••				А
3	3P Housing Wire (J103)	ADX3683			
4	Rear Case Service Assy	ANE1690			
NSP 5	Rear Case (509M)	ANE1682			
1 NSP 6	Rear Case Sheet A 509	AMR3922			-
🗥 NSP 7	Rear Case Sheet B 509	AMR3923			-
1 NSP 8	Rear Shield (509M)	ANK1997			
9	Coil Spring	ABH1125			
10	Power Button	AAD4162			
11	Under Grip R (50F)	AMR3897			В
12	Under Grip LS (50F)	AMR3899			
13	Sensor Cushion B (428)	AEB1486			
14	Under Cover (509M)	ANE1683			
15	Power Button Support	AMR3840			_
16	Terminal Label	See Contrast table (2)			
NSP 17	Name Label	See Contrast table (2)			
18	Caution Label	See Contrast table (2)			
19	Serial Sheet	AAX3143			
20	••••				С
21	••••				
22	Screw (3 x 25 P)	ABA1380			
23	N Grip Screw (M3 x 6)	ABA1381			
24	Screw (B3 x 8)	ABA1389			
25	Screw	APZ30P080FTB			

(2) CONTRAST TABLE KRP-500P/WYSIXK5, WYS5, LFT and WA5 are constructed the same except for the following:

Mark	No.	Symbol and Description	KRP-500P /WYSIXK5	KRP-500P /WYS5	KRP-500P /LFT	KRP-500P /WA5	
	16	Terminal Label 50S-EU	AAX3607	AAX3607	Not used	Not used	
	16	Terminal Label 50S-G	Not used	Not used	AAX3633	Not used	
	16	Terminal Label 50S-CH	Not used	Not used	Not used	AAX3608	
NSP	17	Name Label (50P-EU)	AAL3074	Not used	Not used	Not used	
NSP	17	Name Label (50P-EUJ)	Not used	AAL3075	Not used	Not used	
NSP	17	Name Label (50P-G)	Not used	Not used	AAL3076	Not used	
NSP	17	Name Label (50P-C)	Not used	Not used	Not used	AAL3078	E
	18	Caution Label 50M-EU	AAX3620	AAX3620	AAX3620	Not used	
	18	Caution Label (50P-C)	Not used	Not used	Not used	AAX3622	

KRP-500P

6

5

7

D

F

9.6 FRONT SECTION



FRONT SECTION PARTS LIST <u>Mark No. Description</u>

5

No.	Description	<u>Part No.</u>
1	LED Assy	AWW1399
2	RLS Assy	AWW1401
3	IR Assy	AWW1400
4	6/3/3P Housing Wire (J117)	ADX3712
5	F-Case Assy (500SEP)	AMB3108
6	Blind Cushion (508F)	AEB1479
7	FC Gate Sheet	AMR3906
8	Nylon Rivet	AEC1671
9	Rivet (Plastic)	AEC1877

6

7

8

А

в

С

D

Е

F

	KRP-500P		
6		7	

9.7 CHASSIS SECTION (1/2)



■ 5 ■ CHASSIS SECTION (1/2) PARTS LIST

6

7

8

А

В

С

D

Е

F

-

CHA	551	5 SECTION (1/2) PARTS	LIST
<u>Mark</u>	<u>No.</u>	Description	Part No.
\triangle	1	DC FAN Motor 80 x 15L	AXM1065
\triangle	2	DC FAN Motor 75 x 12T	AXM1066
\triangle	3	DC FAN Motor 40 x 10L	AXM1067
	4	Sub Frame L Assy (509)	ANA2202
	5	Sub Frame R Assy (509)	ANA2205
\triangle	6	F. Chassis V (509M)	ANA2208
\triangle	7	F. Chassis HT Assy 509	ANA2212
\triangle	8	F. Chassis HB Assy 509	ANA2210
	9	Reuse Wire Saddle	AEC2134
	10	Slide Clamp	AEC2166
	11	FAN Bracket	AMR3805
	12	Drive Wire Saddle	AMR3850
	13	FAN Bracket HP	AMR3862
	14	Rear Case Support	AMR3873
	15	Sub Frame Sheet (509M)	AMR3888
	16	Support Bracket 509M	AMR3896
	17	FAN Bracket P	AMR3901
\triangle	18	Front Gasket V50	ANK1963
\triangle	19	Front Gasket H50	ANK1964
NSP	20	FAN Plate	ANG3221
	21	Wire Clip	AEC1948
	22	Screw	ABA1351
	23	N Grip Screw (M3 x 6)	ABA1381
	24	Screw (B3 x 12)	ABA1395
	25	Screw	ABZ30P080FTC
	26	Screw	APZ30P080FTB
	27	Screw	BPZ30P080FTB
	28	Screw	BPZ30P160FTB
	29	Screw	PPZ50P100FTB
	30	Screw	TBZ40P060FTC

5

KRP-500P

6

7

153

9.8 CHASSIS SECTION (2/2)



З

_		5	6			7	0
- СНА	SSI	S SECTION (2/2) PARTS	° –	•			o
Mark	<u>× No.</u>	Description	Part No.	Mark	<u>No.</u>	Description	Part No.
	1	50F DIGITAL Assy	AWW1368		46	DIGITAL Sheet	AMR3822
	2	SENSOB Assy	AWW1340		47	Drive Sheet	AMR3829
	3	50F X DBIVE Assy	AWV2599		48	Y Drive Sheet A (M)	AMR3881
	4	50F Y DRIVE Assy	AWV2600	⚠	49	Power Sheet	AMR3902
	5	••••			50	Reuse Fastener	AEC2133
	6	SENS Assy	AWW1396		51	••••	
	7	FAN CH Assy	AWW1397		52	Screw	ABA1351
	8	POWER SUPPLY Unit	AXY1203		53	Screw	ABA1364
$\overline{\Lambda}$	9	Ferrite Core (F1 - F8)	ATX1072				
	10	Flexible Cable (J201)	ADD1572				
	11	Flexible Cable (J202)	ADD1573				
	12	Flexible Cable (J203)	ADD1574				
	13	Flexible Cable (J204)	ADD1575				
	14	Flexible Cable (J205)	ADD1576				
	15	Flexible Cable (J206)	ADD1577				
	16	Flexible Cable (J207)	ADD1578				
	17	Flexible Cable (J208)	ADD1579				
	18	Flexible Cable (J209)	ADD1580				
	19	Flexible Cable (J210)	ADD1581				
	20	12P/11P Housing Wire (J101)	ADX3677				
	21	11P Housing Wire (J102)	ADX3678				
	22	10P Housing Wire (J106)	ADX3680				
	23	6P Housing Wire (J107)	ADX3684				
	24	5/3/3P Housing Wire (J112)	ADX3686				
	25	5/3/3P Housing Wire (J113)	ADX3687				
	26	5/3/3P Housing Wire (J114)	ADX3688				
	27	5/3/3P Housing Wire (J115)	ADX3689				
	28	5P Housing Wire (J108)	ADX3690				
	29 30	9/3/3P Housing Wire (J130) 7/3/3P Housing Wire (J131)	ADX3691				
		(0.0.)					
	31	Plate Y (509)	ANG3127				
	32	Nylon Rivet	AEC1671				
	33	Flat Clamp	AEC2132				
	34	Nylon Rivet	AEC2089				
	35	Reuse Card Spacer	AEC2117				
	36	PCB Spacer (Reuse)	AEC2122				
	37	Flat Clamp	AEC1879				
	38	Reuse Wire Saddle	AEC2134				
	39	Reuse Card Spacer S	AEC2153				
	40	Reuse PCB Spacer 4.5B	AEC2161				

41	Drive Sheet	AEH1155
42	Drive Sheet Y	AEH1186
43	Power Silicon Sheet	AEH1187
44	Y Drive Sheet B	AMR3769
45	FAN Sheet	AMR3786

5

KRP-500P

6

7

155

8

А

В

С

D

Е

F

А



KRP-500P

5 6 (1) PANEL CHASSIS SECTION PARTS LIST

<u>Mark</u>	<u>No.</u>	Description	Part No.				
NSP	1	P. Chassis Assy	See Contrast table (2)				
NSP	2	50F ADDRESS L Assy	AWW1348				
NSP	3	50F ADDRESS S Assy	AWW1349				
NSP	4	50F SCAN A Assy	AWW1350				
NSP	5	50F SCAN B Assy	AWW1351				
NSP	6	P Panel (50FF) Assy	AWI 11349				
1101	7	Beuse PCB Spacer 4 5	AFC2148				
	8	Heat Radiation Sheet	AEH1134				
	9	Plate Holder	AMR3757				
	10	Holder L Assy (509)	AMR3775				
	11	Holder S Assy (509)	AMR3776				
⚠	12	Address Plate S (509)	ANG3129				
⚠	13	Address Plate L (509)	ANG3130				
	14	Plate X (509)	ANG3128				
	15	PCB Spacer (Reuse)	AEC2122				
	16	Address Silicon TS	AFH1160				
	17	Address Silicon TL	AEH1161				
	18	FC Holder	AMR3895				
⚠	19	Gasket ADH-FCH	ANK1850				
	20	••••					
	21	••••					
	22	Screw	ABA1351				
	23	Screw	ABA1364				

5

(2) CONTRAST TABLE KRP-500P/WYSIXK5, WYS5, LFT and WA5 are constructed the same except for the following:

NRP-	RF-500F/WTSIXR5, WTS5, LFT and WAS are constructed the same except for the following.						
Mark	No.	Symbol and Description	KRP-500P /WYSIXK5	KRP-500P /WYS5	KRP-500P /LFT	KRP-500P /WA5	
NSP	1	P. Chassis (509FE) Assy	AWU1350	Not used	Not used	Not used	
NSP	1	P. Chassis (509J) Assy	Not used	AWU1357	AWU1357	AWU1357	

KRP-500P

7

6

7

8

А

в

С

Е

F

157

9.10 MULTIBASE SECTION

А



2 KRP-500P

		5	6	-		7	8	
(1) MULTIBASE SECTION PARTS LIST								
Mark No.		Description	Part No.	Mark	<u>No.</u>	Description	Part No.	
	1	MAIN Assy	AWW1393		21	Silicon Sheet MTB A	AEH1174	
	2	FAN Assy	AWW1394		22	Silicon Sheet	AEH1177	
	3	AUDIO Assy	AWW1398	\triangle	23	Inlet Shield (509M)	ANK1998	
⚠	4	AC Inlet (CN1)	AKP1336		24	Multi Base Assy SEP	ANA2229	
	5	Flexible Cable (J211)	ADD1582		25	Terminal Panel SEP	ANC2479	
	6	Flexible Cable (J212)	ADD1583		26	AUDIO Heatsink	ANH1723	
⚠	7	Housing Wire (J104)	ADX3679		27	••••		
⚠	8	Housing Wire (J105)	ADX3651		28	••••		
	9	5P Housing Wire (J111)	ADX3706		29	Hexagon Headed Screw	ABA1382	
	10	15P Housing Wire (J110)	ADX3707		30	N Grip Screw (M3 x 6)	ABA1381	
	11	14P Housing Wire (J109)	ADX3708		31	Screw	AMZ30P060FTB	
	12	6P Housing Wire (J140)	ADX3700	\triangle	32	Screw	BMP40P080FSN	
	13	6P Housing Wire (J121)	ADX3709		33	Screw	BMZ30P060FTB	
	14	13P Housing Wire (J133)	ADX3702		34	Screw	BPZ30P080FTB	
	15	3P Housing Wire (J134)	ADX3710		35	Screw	PMB30P060FNI	
	16	7/6P Housing Wire (J116)	ADX3711		36	Screw	See Contrast table (2)	
	17	Wire Saddle	AEC1745					
	18	PCB Support	AEC1938					
	19	PCB Spacer (Reuse)	AEC2087					

С

А

в

5

20 Reuse Mini Saddle

(2) CONTRAST TABLE KRP-500P/WYSIXK5, WYS5, LFT and WA5 are constructed the same except for the following:

AEC2160

Mark	No.	Symbol and Description	Description KRP-500P /WYSIXK5		KRP-500P /LFT	KRP-500P /WA5	
	36	Screw	Not used	AMZ30P060FTB	AMZ30P060FTB	AMZ30P060FTB	1
	36	N Grip Screw (M3 x 6)	ABA1381	Not used	Not used	Not used	

KRP-500P

7

6

Е

F

159

9.11 PDP SERVICE ASSY







PDP SERVICE ASSY PARTS LIST

5

			Mark No.	Description	Part No.
<u>Mark</u> No.	Description	<u>Part No.</u>	26	N Grip Screw (M3 x 6)	ABA1381
NSP 1	P. Chassis (509J) Assy	AWU1357	27	Screw	ABZ30P080FTC
2	Sub Frame L Assy (509)	ANA2202	28	Screw	APZ30P080FTB
3	Sub Frame R Assy (509)	ANA2205	29	Screw	TBZ40P060FTC
4	F. Chassis V (509M)	ANA2208	30	••••	
5	F. Chassis HB Assy 509	ANA2210			
			31	••••	
6	F. Chassis HT Assy 509	ANA2212	32	Pad (5095 T-L)	AHA2772
7	Rivet (Plastic)	AEC1877	33	Pad (5095 T-R)	AHA2773
8	FC Holder	AMR3895	34	Pad (5095 T-C)	AHA2774
9	Support Bracket 509M	AMR3896	35	Pad (5095 B-L)	AHA2775
10	FC Gate Sheet	AMR3906			
			36	Pad (5095U B-R)	AHA2776
11	Gasket ADH-FCH	ANK1850	37	Carton Board (50M JJ)	AHB1318
12	Front Gasket V50	ANK1963	38	Under Carton (5090)	AHD3673
13	Front Gasket H50	ANK1964	39	Upper Carton (509F-SV)	AHD3716
14	Service Pad	AEC2105	40	Protect Sheet	AHG1331
NSP 15	Drive Voltage Label	ARW1097			
			41	Vinyl Bag S	AHG1338
16	Wire Clip	AEC1948	42	Caution Label	AAX3031
17	Drive Wire Saddle	AMR3850	NSP 43	Caution Sheet (9G)	ARM1398
NSP 18	Front Service Assy	AMB3103			
19	Under Grip R (50F)	AMR3897			
20	Under Grip LS (50F)	AMR3899			
NSP 21	Rear Case (509M)	ANE1682			
22	••••				
23	••••				
24	Screw	ABA1351			
25	Screw (3 x 25 P)	ABA1380			

KRP-500P

7

6

161

8

А

В

С

D

Е

F